

codici - codes - códigos - Κωδικοί -
koder - Kody - kódoк - Коды - codului

Brand	Type	Code
@CUBE	TV	1630 1608
@DIKON	TV	1551 1525
@SAT	SAT	4303
@SKY	SAT	4541
1 & 1	TV	1080
1 ONE	TV	1460 1511
A.H.B. TVISION	TV	508
A.R. SYSTEM	TV	0322 0513 0043 1437
AB	see	ABCOM
ABCOM	SAT	4506 4303
ACCENT	TV	0359 0322 0513
ACCESS MEDIA	SAT	733
ACCUPHASE	TV	540
ACCUTECH	see	ACCOUTECH
ACCUTEK	TV	5582
ACEC	TV	0513 0471
ACER	TV	1480 1673 1945
	PC	1945
ACIKO	TV	359
ACOUSTIC SOLUTIONS	TV	0043 1423 1393 1831
	COMBI	0043 0547 1423
ACRONN	TV	500
ACTINA	TV	1400 1837
ACTION	TV	0359 0170
	COMBI	359
ACURA	TV	0513 0359
ADB	DTT	0917 4432 0585
ADL	TV	1975 1398
	DTT	4541
ADMIRAL	TV	1885 0440 0359 1685
ADR	TV	550
ADVENT	TV	1756
ADYSON	TV	359
AEA	TV	0471 0540
AEG	TV	1423 0589 0556 1938 0043 1454 0594 0101 0513 1001 0592 1393 1871 1459 1249 1443 0201 0100 0376 1966 1572 0225
	DVD	1146
	COMBI	1938 1443 0556 0043 1871 0489 1062
	DTT	4541
AG	TV	0556 1338 0557 0595 0550
AGASHI	TV	0322 0513 0359 0471
AGATH	TV	1792
AGB	see	SABA
AGFAPHOTO	TV	128
AGNETA	TV	1716
A.H.B. TVISION	TV	508
AIKO	TV	0513 0359 0337 0471
AIM	TV	0513 0373 1302 0561 0415 0579 0471
AIOSTAY	TV	359
AIR TV	TV	5718
AIRIS	TV	1635 1939 1721 1410 0599 0500 1975 1441 1512 1738 1033 0225 1586 1551 1343 1568 1500 1062
	COMBI	1883 0500 1635 0556 0225
AIRON	TV	1383
AITECH	DTT	917
AIWA	TV	0581 5902 1039 1313 0432 0557 0529 0552 0513 1027 5103 0043
	COMBI	1598
AKAI	TV	0147 0558 1235 0513 1048 1201 0359 0008 1275 1423 1027 1207 0415 0556 0007 0070 0351 1387 1396 0557 0432 0433 0546 0352 0243 0589 0043 1033 0583 0467 1068 0373 1831 5213 5103 0449 0201 0550 0484 5211 1269 0549 0552 0141 1175 5746 5756 5241 0322 1341 1243 1809 1400 5554 5607 5918 1897 1420 1311 1395 1249 1469 0561 0579 1502 0471 0541 5596 0483 1837 1491 0507 5520 5220 1633 0097 1577 1529 5953 6004 1882 0540 6023
	COMBI	0070 1443 0007 0243 1882 0043 0546 0583 0008 0547 1598 1836 0201 1068 0483 1201
AKASHI	TV	322
AKI	TV	0513 1638
AKIBA	TV	424
AKIOS	TV	0043 1423 1042
AKIRA	TV	0599 0579 0423 0101 0513 5358 0371 1502 1485 1301 1357 0141 1338 1420 1251 1849 0128 1840 1001 1873 1884 0511 0487 0508
	COMBI	0371 1352 0599
AKITA	TV	1491 0336 0300
AKITO	TV	0513 0471
AKTRON	TV	424
AKURA	TV	0513 0322 0043 0589 0359 0557 0097 1423 5254 1452 0592 1207 0170 0549 0508 0415 0471 5535
	COMBI	0299 5254
ALBA	TV	0043 0513 0557 0097 1207 1423 0415 0549 0589 0547 0170 0359 1420 0209 0300 0045 5886 1249 1837 1469 1453 1400 1393 1452 1942 0424 0162 1638 0337 1598 0552 0471 0500 1847
	COMBI	1598 0043 1424 1835 1883 1811 1443 1901 0085
ALBATROS	TV	1556
ALBIRAL	TV	0513 0322 0471
ALBRECHT	TV	1586
ALCA POWER	DTT	1343
ALDEN	TV	1559
ALICE	SAT	4419 0744
	DTT	5161

Brand	Type	Code
ALIEN	TV	0043 0097
ALKOS	see	TOSHIBA
ALLSTAR	TV	1201 0513 1384 1207 0471 1027
ALLTEL	TV	1469 1906 1383 0550 1845 0376 0145 1451 0373 1396 1794
ALPHA	TV	0051 1494
ALPHATRONICS	see	ALPHATRONIK
ALPS	SAT	4541
ALTECH UEC	SAT	4647 4649
ALTEK	TV	1494 1396 1395 0557 1526 1975 0101 1845 1401 1546 1383 1529 1394 1840
ALTIUS	TV	432
ALTUS	TV	0557 1400 1837 1435
AMADEUS	see	KOENIG
AMANA	TV	1269
AMBIANCE	TV	1489
AMCOL	TV	0513 0471
AMEX	TV	513
AMIKO	TV	1814
AMINO	SAT	1113 1060 0484 1927
AMITECH	TV	1468
	COMBI	512
AMITRONICA	SAT	4321
AMPLIMSION	TV	1657 0322
AMSTRAD	TV	0513 0043 1423 0589 1469 0322 1559 1454 0415 1343 1410 0440 1440 1556 0359 1511 1578 1587 1460 1849 1638 0473 1721 0424 1569 1880 0471 1435 1551
	SAT	0733 4618 4274 4749 4594 4541
	COMBI	1424 0043 1883 1461
	DTT	4541
ANALOG	SAT	4321
ANAM	TV	0513 0540 0471
ANDERIC REPLACEMENT	TV	0495 0547 1832 1785 1558 1885 1809 1012 1890 1589
ANDERSSON	TV	1423 0043 1887
	COMBI	43
ANDOWL	SAT	5306
ANDROID BOX	see	ANDROID
ANEX	TV	513
ANGELINE DESIGN	TV	555
ANGLO	TV	0322 0359
ANIS	TV	0322 0336 0359
ANITECH	TV	0513 0359 0424 0322 0352 0540 0471
ANKARO	SAT	0919 4288
	DTT	4288
ANSONIC	TV	1048 1109 0043 0511 0322 0357 1423 1942 0513 1657 1897 1136 0376 0319 0201 0097 0336 0359 0141 0471 0244 0589 1046 1053
	COMBI	1443
ANTARES	TV	1549
ANTARION	TV	1423 0576 1048
	COMBI	485
ANUA	TV	1873
ANVISIO	TV	1525
AOC	TV	0045 1494 0051 1053 1955 1086 0415
APACHI	TV	415
APART AUDIO	see	APART
APEX	TV	1809 1352 1536 1971
APPEL SOUND	see	APHEL SOUND
AQP	see	GRUNDIG
AQPROX	TV	1027
AR	TV	1973
ARC EN CIEL	see	THOMSON
ARCAM	HIFI	1337
ARCELIK	TV	0557 1838 1657 0141 0336 0026 0513 1837 0337 0162 1400 0467 1287
	SAT	4506
ARCON	SAT	0919 4303
ARCTIC	TV	0557 0351
ARDEM	TV	0541 0557 0141 0336 1837 0073
ARENA	TV	1423 0209 0043 0557 5886
ARGENTINA	TV	1338 0513 1726 0322 1731 0359 1315 0540 1420 0097 1539 1410
	SAT	4487
ARGON AUDIO	see	ARGON
ARGOS	TV	557
ARIASAT	SAT	4303 4214 4649 4541 4506
ARIELLI	TV	1277 1027 1677 5426 5446 5912 5554 0449
ARION	TV	1677
	SAT	919
ARISTONA	see	PHILIPS
ARKOS	TV	337
ARNION	SAT	4303
ARPHONE	see	DESMET
ARRIS	SAT	4632
ARROX	TV	1400
ARS	TV	0513 0322
ARTAX	TV	1939
ARTHUR MARTIN	see	SALORA
ARTIKELNUM	SAT	4214
ART-TECH	TV	1638 0513 0424 0359 0471
ASA	TV	0556 0513 0433 0471
ASAHI	SAT	686
ASANO	TV	0008 0432 0449 0110 0484
	COMBI	484
ASARO	TV	449
AS-BERG	TV	0513 1420 0471
ASCI	SAT	4541 4321
ASKY BOX	SAT	4541
ASORA	TV	0359 0322
ASPECTS	TV	0201 1964
ASSCOM	SAT	785
ASTHON	see	EMERSON
ASTRA	TV	1485 1809 0359 0513 1112 1251 0579 1302 0424 0415 1502 0561 0471 1882

Brand	Type	Code
ASTRO	SAT	4288
ASTRO SOUND	TV	0513 0471
ASUKA	TV	0322 0513 0471
ATAKI	TV	0359 0424
ATC	SAT	5440
ATEC	TV	1597
ATLANTA	SAT	4321
ATLANTHIA	SAT	4321
ATLANTIC	see	FORMENTI
ATLANTIS	SAT	5320
ATORI	TV	359
ATORO	see	ATORI
ATRON	TV	5586
ATSAT	SAT	4303
AUCHAN	TV	1048 0110
AUDIOLA	TV	1343 0583 1201 0432 0201 0110 0484 1419 1595 0288
	COMBI	0484 0432 0357 0201 0583 0225 0110 0288 1201
AUDIOLAB	HIFI	1337
AUDIOLOGIC	TV	1726
AUDIOSONIC	TV	0513 0557 0359 0336 0141 1400 0541 1837 0209 0424 0322 0484 1657 0554 1638 0561 0471 0043
	COMBI	1883 0359 1835 0484
AUDIOSTAR	TV	424
AUDIOTON	TV	359
AUDIOVOX	TV	1423
AUREX	TV	43
AURIGA	SAT	337
	DTT	5320 0917
AURORA	TV	0513 0359
AUTOCOLOR	TV	359
AUTOSONIK	TV	1396
AUTOVOX	TV	1423 0043 1393 0556 1277 1395 0589 0552 0513 1638 1835 1383 0299 0170 1048 1410
	COMBI	0299 0043 1882 1835
AUX	TV	1556
AUXSTAR	SAT	919
AVA	TV	522
AVENTURA	TV	1558
AVERMEDIA	TV	1515 5261
AVEST	TV	1849
AVION	SAT	919
AVIOUS	TV	1550 1450
AVOL	TV	5325 1559
AWA	TV	0359 0110 0513 0489 1003 0101 1001 0589 0540 0471
	COMBI	489
AWATRON	TV	359
AWE	COMBI	110
AXANE	TV	513
AXEN	TV	5307 1486 1384
AXIL	TV	1201 0583
	SAT	4321
	DTT	4541 0686
AXION	TV	0415 0513 1420 0359 0471
AXITRONIC	SAT	4321
AXON	TV	0557 1338 0561
AXXENT	TV	0513 0043
AXXION	TV	415
AXXON	see	AXON
AYA	TV	1048 1423 0043 5328 0110 1247 5931 0101 1031 0432
AYCO	TV	1491
AZ - BOX	SAT	547
BAFF	SAT	686
BAIER	TV	556
	COMBI	1443
BAIRD	TV	0373 1741 1964 1454
BALMET	SAT	1754
BANG & OLUFSEN	TV	513
BASIC LINE	TV	0043 0513 1423 0424 0097 0557 1942 0541 0141 0359 1726 0373 1142 0540
BAUER	TV	0513 0561 0351 0467 0508 0528 1313 1302 1964 0352 1300 0495 0471
BAUHN	TV	0432 5224 5972
BAUMATIC	TV	322
BAUNZ	TV	1027
BAUR	TV	0513 0467 0351 0359 1313 0528 0508 0352 1300 0339 0140 0495 1069 0471 0337
BAYERE	TV	0205 1931
BAYSONIC	TV	322
BAZIN	TV	0162 0513
BAZZIX	COMBI	1882
BBK	TV	1148 1921
BEAUMARK	TV	547
BEKNEKNIK	TV	1657 0467 0337 0557
BEKO	TV	0557 0336 0141 1400 1837 0541 1838 1657 0513 0026 0504 0337 1942 1435 0162 0467 0043 1459 0552 0097 0540
	SAT	4506
	COMBI	1836 1443 0483 0504
	DTT	1057
BELLAGIO	TV	1896
BELSON	TV	1840 1423 0485 0145 0101 1015 1459 0043 1633 5255 1884 1876 1831 1412 1410 1001 0110 1357 1511 1839 1452 0498 1027 0205 0286 0306 1099 1142
	COMBI	485
BELSTAR	TV	0592 0043 0513 1942
BENJAMIN	SAT	4506 4541
BENNET	TV	0513 0540
BENQ	TV	1593 1053 0053 1086 1033 5335
BENSTEN	TV	1511 0550 0145 1491 1469 0376 1949
	COMBI	1461

Brand	Type	Code
BEON	TV	1356 1420 1721 0513 0336 1400
BEOND	TV	1721 1400
BERKENP	TV	513
BERKLAYS	TV	1235
BEST	TV	0516 0556 0513
	SAT	919
BESTAR	TV	1657 0513 0043 0359 0336 0162 0415 0592 0471 0322
BIAZET	TV	513
BIFONIC	TV	359
BIG SAT	SAT	4541
BIGSTON	TV	0359 0322
BITMORE	TV	1716
BJORN	TV	1716
BLACK DIAMOND	TV	0043 0209 0527 1613 1423
	COMBI	43
BLACK STRIP	TV	337
BLACKTRON	TV	0424 0359
BLACKWAY	TV	0424 0351
BLANCA	TV	154
	SAT	733
BLAUBERG	TV	5426
BLAUPUNKT	TV	0351 1114 1036 1052 1051 1551 1678 0522 0540 0527 0352 1537 5827
BLAUREN	TV	1910
BLAZER	DTT	686
BLOOM	TV	0043 1845 1578 1423 1454 1396 0556 1975 1494 1412 1511 1394 1484 1450 0589 1537 1820 1896
	COMBI	1883 1423
BLU:SENS	TV	1046 5515 0014 1055 1897 0487 1995 1030 0244 0319 5268 1132 0036
	COMBI	1055 0014 1897 1046 1081
BLUALTA	TV	5275 5426 1235 5829
BLUE	TV	5596 1247
BLUE DIAMOND	TV	1052 1036 1235 1201
BLUE MEDIA	TV	1590
BLUE STAR	TV	0162 0513
	COMBI	1598
BLUEH	TV	0053 1915
BLUESKY	TV	0043 0557 0513 0541 1423 0322 0589 0141 0376 0556 0097 1454 1556 0051 1722 1452 1459 1760 0170 1788 1529 0549 1944 0552 1942 1393 1435 1837 0053 1740 0073 1539 1887 1207 1400 1142 0555 1836
	COMBI	1598 0537 0043 1423
BLUETECH	TV	0405 1056 1966 0288 1062 0205 0225 1100 1831 1129 1469 5211 0432
	COMBI	405
BLUETINUM	TV	1551
BOCA	SAT	4288
BOGO	TV	0500 1201 1129 1027
BOIGLE	TV	1989 1440
BOLVA	TV	5248 5375 5446 1114
BOMAN	TV	0556 1525
BONSTEC	TV	359
BORK	TV	1506
BOSS	TV	0322 1420
BOTECH	SAT	4651 4303 0919
BOUYGUES	see	BOUYGUES TELECOM
BOXFORD	TV	1437
BPL	TV	0513 0373 0424
BQS	TV	0043 0513 0051 1313 0552 1249 1739 1838 0064 0070 1558 0522 0073 0359
BRANDT	TV	0051 0043 0110 1048 1423 5211 1247 1006 5220 1494 0432 5596 1435 5240 1103 0007 1027 1282 5348
	COMBI	43
BRANDT ELECTRONIQUE	see	THOMSON
BRANIFF	TV	1726
BRAUN	TV	51
BRAVUS	TV	484
BREMEN	TV	43
BRENDSTAR	TV	359
BRIGMTON	TV	1831 0513 1939
	COMBI	0325 1133
BRIMAX	TV	1529 1939 1572 1983 1594 5255
BRINKMANN	TV	0513 0209
BRIONVEGA	TV	0440 0513 0589
BRITANNIA	TV	513
BROKSONIC	TV	513
BRONDI	TV	1419
BROTHER	TV	0322 0359 1243 0513 0561 1251 0579 0043 1302 0547 0529 1907 1506
BROTHERS	TV	0561 1506
BRUNS	TV	0336 1207 0352 0322 1429 0592 0359
BSKYB	SAT	4618 4594 0733 4603 5146 4749
BSL	TV	5426
BSR	TV	300
BULSATCOM	SAT	4651
BUSH	TV	0043 0513 1837 0097 1423 0557 1048 0415 1400 0589 1454 1207 0209 0549 1053 0373 5886 1838 1393 0359 0045 5271 0170 1396 1452 1556 1057 1601 1831 1942 1356 0300 1941 1142 1469 1235 1114
	COMBI	1598 1443 1461 0043 1811
BUTTERFLY	TV	1729
C.P.	TV	1716
CABOVISAO	SAT	4303
CADMOS	TV	359
CAHORS	TV	1048
CAIRN	HIFI	1337
CAIXUN	TV	5446 1027
CALIFORNIA	see	FORMENTI
CALVAS	TV	5928

Brand	Type	Code
CAMPER	TV	0336 0513 0141
CAMPIONE	TV	1048 1027 0008 1201 1423 1235 0513 5103 5220 1070 0101 0032 5253 0357 0583 0485 0408 0488 1303 0500 1113 1242 1129 5607 0021
CANAL +	SAT	785
CANAL CUBE	see	CANAL +
CANAL DIGITAL	SAT	4541
CANAL PLUS	see	CANAL +
CANAL SAT	SAT	785
	DTT	785
CANALSANTE	see	SIDEC
CANARIA	COMBI	0036 1897
CANCA	TV	1511
CANDLE	see	LG
CANON	TV	1338
CAPSONIC	TV	0322 0513
CARAD	TV	0043 0513 0070 0073
	COMBI	1461
CARENA	TV	0513 0541 0540
CARPO	TV	1831 1351
CARREFOUR	TV	1313 0540 1366 0527 0051 0043 0513 0528 0209 0555 1300 0351
	COMBI	0522 0537 1310 1429
CARTEL	TV	556
CARYONSE	see	PHILIPS
CASCADE	TV	0513 0359
CASIO	TV	0513 0540
CASONIO	see	OCEANIC
CASTLE	TV	513
CAT	TV	1529 1577 1535 1536
CATHAY	TV	0513 0540
CAV	TV	1282
CCE	TV	513
CDV	TV	1410 1464 0286 0288 1428 0485 1978 1983
	COMBI	1440
CEEM	TV	557
CELCUS	TV	1423
	COMBI	1423 1048
CELESTIAL	TV	1809
CELLO	TV	1443
	COMBI	1443
CELTRONIC	TV	589
CENTRUM ARIES	TV	1249
CENTURION	TV	0513 0540
CGE	TV	1420 0513 0162 0359 0351 1638
CGM	TV	1657 0513 0359 0336 0043 0097 0322 0424 1942 0415 0541
CGV	TV	1048
	DTT	733
CHALLENGER	SAT	785
CHAMELEON	TV	1729
CHANGHONG	TV	1247 1850 5566 1556 1070 0110 5586 0366 5596 0334 5830
	SAT	6034
CHANNEL-TOUCH	HIFI	1805
CHARISMA	TV	1479
CHARPY	TV	1891
CHEROKEE	SAT	4321
CHESS	SAT	4288 4541 4321
	DTT	4288
CHIQ	TV	5568 5830 5586 1247 5566 5596
CHRISTIAN	TV	1716
CHROMIA	TV	1027
CIE	TV	0359 0513
CIHAN	TV	0513 0162 0359 0322
CILLA	TV	1716
CIMLINE	TV	0359 0300
CINEMA	TV	43
CINEX	TV	0589 1454 0556 0170
	COMBI	1443 1461
CISCO	SAT	4603
CITIZEN	SAT	919
CITTA MERCATO	TV	0513 0541 1313
CITY	TV	359
CLARITRONIC	TV	1657 0556
CLARVOX	TV	0513 0540
CLARKE TECH	SAT	0035 4506
CLATON	TV	513
CLATRONIC	see	CTC CLATRONIC
CLAYTON	TV	0043 1048 1423 0513
CLEAR VIEW	SAT	4303
CLEMENS CAMPUS	see	HUTH
CLINTON	TV	359
CLOUD - IBOX	see	CLOUD
CM@X	TV	485
CMX	TV	0485 0243
COBRA	TV	556
	SAT	4506
COBY	TV	1857 1046 0007 5745
	COMBI	7
COFADEL	see	THOMSON
COLISEE	SAT	1113
COLLE	TV	1716
COLOMBIA	see	COLUMBIA
COLOR	TV	0556 1485 0557 0359
COLORTAC	TV	1515
COLOSSUS	TV	1027
COLT	TV	1429
COLUMBIA	TV	0513 0471 0336
COLUMBUS	TV	513
	SAT	4321
COMAG	SAT	4288 4214 4541
	DTT	4288 4541
COMBITECH	see	ORION
COMELEC	TV	0584 0513 1423 1685 1622 0043

Brand	Type	Code
COMET	TV	0589 0513 0556 1394 0550 1500
COMEX	TV	1792
COMMANDER	SAT	4651 0686
COMMAX	TV	1461
COMPUTEC	TV	1451
COMPUTRON	TV	0415 0359 0433 0513
CONCERTO	see	LG
CONCORDE	TV	359
CONDOR	TV	0513 0359 1420 0424 0322 5566 0043 0541
CONFORAMA	see	SONOLOR
CONIA	TV	557
CONNECT	TV	1451
CONNEXIONS	TV	1313 0467 1366 1429
	COMBI	64
CONNEXIONS CX	see	CONNEXIONS
CONRAC	TV	1435
CONRAD	TV	0043 0209
	SAT	4214 4127 4541
	DTT	4214
CONRAD ELECTR	see	CONRAD
CONSTRUCTA	TV	540
CONTEC	TV	0359 0322 0424 0513 0561
CONTEX	TV	1027
CONTI M	TV	0043 0513 0557 0141
CONTINENT	TV	0209 0073 0513 0105
	SAT	744
	COMBI	537
CONTINENTAL	TV	0549 0513 1048 5211
	COMBI	1443
CONTINENTAL EDISON	TV	0549 1048 0008 1423 1201 0051 1207 0170 0423 0513 0588 1068 5426 0101 0556 1027 1235 5286 5220 0110 0432 5903 5927 1001
	COMBI	1445 0008
COOCOA	TV	5987 5764 5970 1604
COOLSTREAM	see	CST
CORFUNCO	TV	322
COSMEL	TV	0359 0513 0540
COSMOS	TV	0359 0513 0556
CPR - TEC	TV	0389 1793
CPTC	TV	376
CRANKER	TV	1048 5103 1351 1175 5446
	DTT	4432
CRC	TV	0513 0471
CREA	SAT	919
CROSLEY	TV	0513 0541 0516
CROSSWOOD	TV	0043 1423
CROWN	TV	0513 0557 1657 0541 0043 0336 0359 1638 1942 0549 0141 1420 0205 0097 0322 1423 1837 1247 1437 0550 0592 1400 0556 0563 0415 0540 0589 1613 1122 1027 0011 0516 1838 0579 0209 1491 0300 0528 1594 0299 1070 0583 1201
	COMBI	0537 1598 0043 0299
CROWN MUSTANG	TV	1420 0513
CRYSTAL	TV	0513 0592 0336 0541 0555 0589 0043 0471
CRYSTAL IMAGE	see	CRYSTAL
CRYSTAL VISION	TV	1449
CTC CLATRONIC	TV	0513 0557 1420 0556 1942 1423 0043 0322 0589 0415 0541 0026 0097 0359 0170 1249 1459 0424 1643
	COMBI	0043 1461
CUBE	TV	1630 1608
CURTIS	TV	0286 0513
CwR - TECH	TV	0556 0592 0557
CXC	see	EMERSON
CYBERCOM	TV	1400
CYBERPIX	TV	0043 1423
CYFRA	SAT	785
CYFRA PLUS	see	CYFRA
CYV	TV	513
D - LINK	SAT	5699
D - SMART	SAT	4303
D - VISION	TV	0513 0554 1721 1938 0352 0589 0209
	COMBI	1461 1443 0043 1938 0188
D@TACOM	DTT	686
DAANGARD	TV	1897 1989 1133 1831 1865 1844
DAENYX	COMBI	1601 0557
DAEWOO	TV	0209 0554 1601 0513 0171 0359 1613 1450 1507 0557 1866 0085 1400 1942 1838 5454 0541 1759 1336 0352 1412 1449 1459 0043 5658 1453 0556 0141 1758 1870 1235 5971 1643 0592 1383 1760 1837 1017 1148 1897 0319 5458 0371 0015 0244 0589 0110
	VCR	537
	COMBI	1613 0537 0325 0085
DAICHI	TV	0359 0209
DAIMOND	TV	513
DAITSU	TV	0594 1423 0565
DALMAN	TV	1453 5929 0556
DANE - ELEC	TV	1844
DANGAARD	TV	1897 1133 0036 1989 1844 1865 1831
DANSAI	TV	0513 0337 0556
DANTAX	TV	1423 1400 0043 0513 0141 1837 0557 0336 0541 1838
	COMBI	1423 0043
DATRONIC	TV	359
DATSUN	TV	1726
DAVOS	TV	0547 0495 0467 1726 0351 5900 0513 1429 1805 1539 1410 0322 0359 1420 0427 1466 0581 0051 0339 1885
	SAT	4487
DAWA	TV	0513 0359
DAYMATER	see	MAGNADYNE
DAYTECK	TV	1449
DAYTEK	TV	1568 1450 1850 0513
DAYTON	TV	1568

Brand	Type	Code
DAYTRON	TV	0359 0513
DAYTRONIC	see	DAEWOO
DCE	TV	0043 0557 1393
	SAT	4321
DDREAM	see	DREAM
DE DIETRICH	TV	424
DE GRAAF	TV	0513 0162 0043
DECCA	see	TATUNG
DECCA VIDEO	VCR	540
DECTRON	TV	1449
DEDIETRICH	TV	424
DEFLEXION	TV	484
DEITRON	TV	0513 0540
DELIPS	TV	1423
DELL	TV	289
DELTA	TV	513
DELTON	TV	0043 0557 1837
DEMACOLOR	TV	513
DENKO	TV	322
DENON	TV	473
	HIFI	285
DENTAL	see	FORMENTI
DENVER	TV	1220 5248 0513 1897 1546 5931 0359 1638 1630 0556 0576 0424 1551 0319 1410 0511 5426 0325 0043 1343 1572 1595 1078 0399 0484 1559 1382
	COMBI	0576 1424 0325 1883 1482 0556 1938 0484 0511 1897 0563
DESMET	TV	0513 0541 0043 1642 0555 0359 0467
DEVISION	TV	0513 0554 0043
DGM	TV	0563 0483
	COMBI	0483 0299
DHS	see	ASTRA
DIAMANT	TV	0513 0540
DIAMOND	TV	0209 0554 0359 0513 1601 1450 1338 0171 0352 1449 1807 1973 0541 1412 1759 1758 1112 0561 1301 0557 1453 1017 1459 1760 1507 1866 0043 1613 5279
	COMBI	0537 1613 0085
DIBOSS	TV	1516 1400 1937
DICRA	TV	1027 1031 0399 0005 0286 0101 0507 1343 0299 1551 1595 1419 0500
	COMBI	0299 0399 0101 1027
DIFAO	TV	5305
DIFFE	TV	1514 1489
DIFFERO	TV	1423
DIGATRON	TV	0513 0540
DIGI	SAT	4288
DIGIALITY	SAT	4541
DIGIAN	SAT	4506 4541
DIGICAG	SAT	4303
DIGICOM	TV	1429
DIGIFUSION	TV	1435 1838 0557
DIGIHOME	TV	1423 1048 0043 1857
	SAT	919
	COMBI	43
DIGILINE	TV	0513 1207 0555
	SAT	4303 0686
DIGILOGIC	TV	1423
	COMBI	1883
DIGIMASTER	SAT	919
DIGIMATE	see	DGM
DIGINIUM	TV	1454 0589
	COMBI	1443
DIGIPOL	SAT	5168
DIGIQUEST	TV	1048 1027 0011 5103
	SAT	4303 4166 4603
	DTT	4432 4910
DIGISAT	DTT	5320
DIGITAL	SAT	4541 4288 0919 0785
	DTT	4541 4288
DIGITAL +	SAT	785
DIGITAL BOX	SAT	4214 4127
	DTT	4214 5440
DIGITALB	SAT	4303
DIGITALB - HD	see	DIGITALB
DIGITEK	TV	1760 1529 1971
	COMBI	1835 0556
DIGITOR	TV	0359 0513 0540
DIGITREX	TV	0484 0514
DIGITRONIC	TV	1048
	SAT	919
DIGITSAT	DTT	5320
DIGITURK	SAT	0513 0785
DIGIX	TV	1450 1820 1412
	SAT	4303
DIK	TV	0513 0322
DIKOM	TV	1048 1831 1423 0599 0205 0500 1595 1343 1578 1873 1062 1551 1880 1027 1491 1525 1781 0201 0286 0002 0007 1938 0576
	COMBI	1831 0500 0225 0507 1856 0201 0205 0556 0299 1440 0188 0005 1835 1633 0599 0100
DINASTY	TV	0043 0359 0513
DION	TV	1897
DIOPUS	TV	594
DIPRO	DTT	917
DIPROGRESS	DTT	5320
DISCOVERY	TV	1346
DISEQC	SAT	4321
DISNEY ELECTRONICS	TV	5886
DISTAR	TV	513
DIUNAMI	TV	0188 1727 0583 0201 0599 1949 1741 1873 1460 1556 0484 1062 1201
	COMBI	0484 1062
DIVERSEN	TV	586

Brand	Type	Code
DIVISION	TV	1938
DIXI	TV	0513 0359 0540
DIXON	TV	5932
DM TECH	TV	1542 1489 1739 0576 1514 1988 1423 0043 0128 0511 1968 0101 0325 0319 0423 0489 1897 1027 0036 0487
	COMBI	0576 0511 0128 0325 0043 1514
DMS	TV	1301 0484
DMSIS	SAT	4506
DMTEK	TV	43
DOMEOS	TV	0209 0513 0097 0043 0592
DOMLAND	see	DUAL
DOMOH	TV	513
DOMUS	TV	513
DPM	TV	0557 1400 1529 0263 0556 1011 1938 0550 1506 1838 1594 1837 0357
DQ	see	DIGIQUEST
DRAKE	SAT	4541
	DTT	4541
DREAM	SAT	919
DREAM - MULTIMEDIA	see	DREAM
DREAMVISION	SAT	919
DRS	TV	322
DSE	TV	0110 0101
DSM	TV	1027 0432
DSN	SAT	4303
DSR	SAT	4506 0919
DSTV	SAT	4649 4647 0917
DTM	SAT	919
DTS	TV	0359 0209 0440 0513
DTT NUMERIQS	DTT	1132
DUAL	TV	0209 0513 0359 0043 1423 0592 0440 0170 1249 0097 0557 0432 1489 1400 1938 0552 0556 5886 1048 5286 0352 1942 0589 0558 0141 0547 0162 1839 0471 1884 1060 5426
	COMBI	1884 0043 1423
DUAL - TEC	see	DUAL
DUMONT	TV	0513 1420 0043 0541 0373 0105 0556
DUNE	TV	1169
	PC	1169
DUNE HD	TV	1169
DUNLOP	TV	128
DURABASE	TV	1048
DURABRAND	TV	1558 0043 0557 1400 0552 1423 1249
DUX	TV	513
DVB	SAT	4541
DVDO	TV	1396
DYNAMIC	TV	0359 1420
DYNASTY	TV	43
DYNATRON	TV	0513 0471
DYON	TV	1201 0489 1001 5903 5328
EA	TV	1743
EAS - ELECTRIC	TV	1048 1622 1351
EASY LIVING	TV	1743 1529 1396 1756 1484 1904 1454 1400 1394 1975 1894 1814 1848 1398 1525 1868 1397 1963 5886 1939 0592 1845 0557 1449 1401 1817 1879 0556 0100 1632 1422 1551 1554 0589 1876 1537 1578 1594 1410 1741 1078
	COMBI	1835 0556 0299
EASYGNIA	see	BEST BUY
E-BODA	TV	1556
ECCO	TV	1346 5982
ECG	TV	0557 1938 1838 1027 1400 1837 0484 1452 1057 0483 1070 0110
ECHO	TV	561
ECHOLITE	SAT	4541
ECHOSAT	SAT	4303
ECHOSTAR	TV	0513 0359 5718
	SAT	0791 0785 0744
ECO LINE	TV	513
ECONET	SAT	5146
ECRON	TV	1423 0043 0511 1452 1840 0244 1578 0557 0319
EDAN LINE	TV	0513 0043
EDENWOOD	TV	1048
EDISION	TV	1788
	DTT	919
EDISON	TV	549
EDISON MINERVA	TV	0549 1112
EDVIN	TV	1716
EF COMPONENTES	TV	0528 0351 0547 0495 1315 1268 0467 1207 0540 1805 0373 1429 1382 1950 0051 1785 0352 1259 1716 0581 1832 0167 1589 0021 0339 1313 0586 1366
	SAT	4487
EFIMATICA	TV	484
ECC	TV	1247
EI	TV	1423 1657
EINHELL	SAT	4214
EIZO	TV	5321
EKSELANS	SAT	5320
EL	TV	1743 1529 1396 1484 1756 1454 1394 1904 1400 1975 1814 1525 1398 1894 1868 1397 1963 1848 5886 0557 1449 1401 1817 1939 1879 0592 1632 1551 1845 1578 1594 1554 0556 1876 0100
	COMBI	1835 0556
ELBE	TV	0043 0105 0440 0589 1838 1048 0513 0541 1423 1452 0073 1451 1454 0557 1400 1990 0209 1450 1529 1449 0170 1453 0528 1594 1595 1939 1940 1942
	COMBI	1443 0043
ELBIT	TV	513
ELCART	DTT	5320
ELCIT	see	MAGNADYNE

Brand	Type	Code
ELECTRA	TV	5984 0359 1301 0561 1556 0043 0322 1809 1459
ELECTRIC	TV	1837 0043
ELECTRIC. CO.	TV	43
ELECTRICCO	TV	43
ELECTRO TECH	TV	359
ELECTROHOME	TV	1423
ELECTRON	SAT	919
ELECTRONIA	TV	1423 1048
ELECTRONICS	TV	322
	COMBI	1882
ELECTROVENDA	TV	513
ELED - TV	TV	1201
ELEKTA	TV	0322 0359 0513 0424 1942 0471
ELEKTRA	TV	0500 1633 1027
ELEKTROMER	TV	0043 0513 0359 0589 1423 1942 0339 0021 1333 1429 0528 0351 1393 0552 0097 1313 1466 0467 0550 1849 1420 1112 1249 0209 0540 1495 1300 1308 0140 0495 0322 0565 1382 0051 1556
	SAT	4303 4506 4787 4541 0919 0686 0513 0589
	COMBI	0043 1443 0051
ELEKTRONIKA	TV	0513 0592 0043 1657 0516
ELEMIS	TV	0589 1454 0513 0043 0336
	COMBI	1443
ELENBERG	TV	1539
ELFUNK	TV	0043 1423 0547 1847
ELG	TV	0513 0540
ELIN	TV	0513 0433 0359 0540
ELINLUX	TV	541
ELITE	TV	1870 1491 0513 0322 1849 1346
	DTT	686
ELKOR	SAT	4214
ELKOS	TV	1048 1677
ELLEVISION	TV	0322 0425 0527
ELLIES	TV	0410 0583
	SAT	4647 4649
	COMBI	366
ELMAK	TV	513
ELONEX	TV	1756
ELSAG DATAMAT	see	ELSAG
ELSAY	TV	0513 1556 0471
ELTA	TV	0359 0162 0322 0513 0589
EL-TECO	TV	1484
ELTON	SAT	4541
ELUNEX	TV	1756
ELVA	TV	359
EMATEC	see	OCEANIC
E-MAX	TV	0556 1450 1410
EMCO	see	IMPERIAL
EMERSON	TV	0513 1558 1657 0415 0043 0299 0336 1835 0541 0322 1638 0097 0547 5614
EMME ESSE	SAT	785
	DTT	917
EMOS	SAT	5320
E-MOTION	TV	1114 1756 1412 0556 1036
EMPIRE	TV	0513 1743
ENERGY SISTEM	TV	1027
ENGEL	TV	0583 1201 5764 5446 1027 1048
	SAT	785
	DTT	4541 0686
ENIE	TV	529
ENKOR	TV	6025
ENOX	TV	1033
ENTONE	TV	1989
ENZER	TV	0595 0561 0579
EP SAT	see	PACE
ERAE	TV	1459
ERC	TV	1849
ERGO CLASS	TV	1033
ERIK	TV	1716
ERISSON	TV	1556 1340 1879 1341 1428 0561 1502 1376 1980 0579 1529 1882 1638 1849 0595 1787 1338
	COMBI	1897
ERRES	see	PHILIPS
ESA	TV	1558
ESC	TV	0513 0373
E-SPACE	TV	5789
	SAT	919
	DTT	919
ESPECTA	TV	1788
ESSAT	TV	541
ESSENTIEL	TV	1048 1220 1831 1276 5252 0484 0592 0044 1423 1607 1140 1630 0324 1282 0043 1290 0485 1876
	COMBI	0556 1048
ESSENTIEL B	see	ESSENTIEL
ESTAR	TV	1027
E-STAR	TV	1027
ESTELLE	TV	513
ETCO	TV	0352 1207 0540 1366 0584 0585 0513 0586 0170
	SAT	4127 0540
	COMBI	522
ETERNITY	TV	1756 1412 1450 1114
ETON	TV	359
ETRON	TV	0359 0162 0415 0513
EULANDER	see	ELBE
EUREKA	TV	0513 0359 0322
EUROBOX	SAT	373
EUROCOLOR	TV	1423
EUROFEEL	TV	0322 0513 1207
EUROLINE	TV	0540 0513 0408 1423 0587
EUROMAN	TV	0513 0322 0359 0516 0336
EUROPA	TV	0513 0592 0359

Brand	Type	Code
EUROPHON	TV	0513 0592
	SAT	4288 4541
	DTT	4541 4288
EUROSKY	TV	0589 0043
EUROSOUND	TV	1343
	COMBI	0561 1440 0288
EUROSTATUS	TV	0513 0043
EUROTRONIC	TV	513
EUROVISION	TV	1423 1393
EVELUX	TV	0592 0043 0513 1423 0516 0373 0051
EVERGOLD	TV	549
EVERLINE	TV	1118 0583 1201
EVOLVE	TV	1767
EVOTEL	TV	1938 0599
EXCEL	TV	0513 0540
EXCLUSIV	TV	0484 1027 1070 1247
EXCLUZIT	TV	513
EXCORS	COMBI	1440
EXEAL	TV	322
EXOLYS	TV	1118 0008
EXON	TV	0557 0141
EXQUISIT	TV	0541 0513
EXTREME BOX	SAT	686
EYCOS	SAT	919
F & J	TV	511
	see	F & U
F & U	TV	1423 1048 1027 5446 0548 0387 0043 1175 0399 1559 1633 1440 0244 0599 0511 1863 5259 1837 5830
	COMBI	128
FA	TV	415
FAGOR	TV	0359 0162 0513 0322 1235
FAIR MATE	TV	0322 0563
	SAT	4541
FAIRMOST	TV	359
FAIRTEC	TV	1459 0594 0389 1953 1548 1722 1568 1571 1954 0043 1944 1423
FALCON	TV	359
FAMILY LIFE	TV	0513 0540
FELIX	TV	0322 0415 1938 0557 1638 0507 1633 0484
	COMBI	1873 0484
FELSEN	TV	432
FELSON	TV	1048
FENNER	TV	0043 0359 1423 0513 1207 0424 1469 1460 0516 1452
	COMBI	0043 0359
	DTT	4432
FERGUSON	TV	0051 1423 0043 0209 5886 5735 1207 1048 0373 5934
	SAT	919
	COMBI	0537 5447 5735
FERRI	TV	0557 0043
FIDELIS	TV	0513 0359 0043
FIDELITY	TV	0513 0043 0415 0359 0508
FIGAR	TV	516
FIL	TV	376
FILMNET	SAT	785
FILSAI	TV	359
FINEST	SAT	4303
FINLANDIA	TV	0433 0373 0472 0147
FINLUX	TV	1423 1048 0558 0589 0147 0556 0043 0513 0433 0557 1454 1420 1760 0352 1643 1207 1434 1459 1435 1847 0359 0592 5446 0540 0471 0555
	COMBI	1443 1423 0043 1461
FINNSAT	SAT	4214
	DTT	4214
FIRST LINE	TV	0513 0043 0557 1423 0359 0097 0376 0352 1459 0552 1400 0373 1435 1420 0589 0540 0508 1453 1942 0073 0541 0162 1760 1454 0527 0209 0471
	COMBI	0043 1443
FISHER	TV	0373 1657 0513
FLINT	TV	0513 0073 0541 0322 0209 1220 0043 0424 1831 1351 5251
FLORISTAL	TV	322
FLYCOM	SAT	4541
FMD	SAT	4321
FOCUS	TV	1400
FOCUS - SAT	SAT	4303
FOITECH	TV	43
FONESTAR	DTT	4432
FORCE	TV	1423
FORGESTONE	see	THORN
FORMENTI	TV	0513 0043 1420 0322 0541 0162 0359 0170 0552 0471 1642 0589 1048
	COMBI	43
FORTEC STAR	SAT	0686 4166 4651
	DTT	686
FOX	TV	0500 1091 0484
FOXTEL(AU)	SAT	5718
FRABA	TV	513
FRABER	TV	513
FRACARRO	SAT	0785 4541
	DTT	917
FREDIKSON	TV	0589 0555 0513
FRIAC	TV	0513 0540
FRIGOR ELECTRONIC	SAT	4321
FRONTECH	TV	0359 0322
FS SOUND	TV	0359 0170
FTE MAXIMAL	SAT	5320
	DTT	686
FUBA	SAT	4321 4303
	DTT	4303

Brand	Type	Code
FUEGO	TV	1247 1027 0599 1837 5251 5554 1838 1529 1633
FUJI	TV	0513 1831 0424
FUJI ONKYO	TV	1048
	SAT	4288
	DTT	4288
FUJI SOUND	TV	424
FUJICOM	TV	1428 1396 5991 1100 0225 1048
FUJITECH	TV	513
FUJITSU	TV	1408 1743 1435 0513 1423 1759 5738 0440 0043 1568 1396 1638 1398 1643
FUNAI	TV	1558 0043 0322 0193 0557 1120 0513 1423 1743 1249 5900 0097 0552 0359 0595 1027
FURICHI	TV	595
FUSION	TV	1435 0557
FUTRONIC	TV	1338 0322 1127
FUTURE	TV	0513 0540
FUTURETECH	see	EMERSON
GABA	TV	1870
GALACTEX	TV	322
GALANT	TV	0415 0424 0359
GALAXI	see	FORMENTI
GALAXY - GALAXIS	TV	0513 1420 1942 0336 0547 0352
	SAT	785
GALAXY INOVATION	see	GI
GALERIA	TV	359
GARRARD	TV	1515 0513
GARZA	TV	1452
GBC	TV	0359 0513 1489 5953 0500 0424 0043 0415 1551 1419 5375
	COMBI	1489 0101 0043
	DTT	5440 5320 4127
GE	see	RCA
GEANT - ELECTRONICS	see	GEANT
GEANT CASINO	see	OCEANIC
GEC	TV	0513 0162
GELOSO	TV	359
GEMSOUND	TV	359
GENERAL	TV	0359 0513 1879 0209 0440 0336 0471
GENERAL CORPORATION	TV	43
GENERAL ELECTRIC	see	RCA
GENERAL INSTRUMENT	SAT	4487
GENERAL STAR	TV	547
GENERAL TECHNIC	TV	0359 0513 0209 0322 0440
GENESIS	TV	0513 0540
GENEXXA	TV	540
GENUINE	TV	1423
GERICOM	TV	1383 1759 1435 1398 1569 1412 1597 1788
GERMANVOX	TV	1423 0043
GESAT	see	G - SAT
GETTER	TV	1048
GIANT	TV	0527 0513 0359 0561 0471
GIGA	see	GIGA TV
GITEM	TV	0513 0351 0471
GLOBAL	SAT	4541
GLOBO	SAT	4541 4288
	DTT	4288 4541
GM - GMC	TV	0359 0513 0322 1420
GMC	see	GM - GMC
GMI	SAT	4288
GOGEN	TV	1423 0043 1048 1249 1622 1142
GOLD	TV	1813 1537 1578 1985 1526 1721 1729 1896 1983 1338 0488 0044 1876
	COMBI	1938 1897
GOLD TOP	TV	424
GOLD VISION	SAT	919
GOLDBOX	SAT	785
GOLDEN INTERSTAR	DTT	686
GOLDEN MEDIA	SAT	686
	DTT	686
GOLDEN TRADING	TV	73
GOLDFUNK	TV	0097 0043
GOLDHAND	TV	359
GOLDI	TV	170
GOLDLINE	TV	0073 0424
GOLDMASTER	SAT	4541 4303 0919 4787
GOLDMASTER OLIMPIA	SAT	919
GOLDSTAR	see	LG
GOLDSUN	TV	424
GOLDTECH	TV	0043 0097 0513
GOLDTOP	TV	424
GOODING	TV	549
GOODMANS	TV	0043 1423 0513 0209 0557 0415 0554 0352 0589 1454 1400 0097 1838 1393 1601 0541 1396 1837 0051 0359 1450 1142 0558 1657 0141 1435 0147 1207 1979 1412 1598 0170 0592 0337 0322 0351 1529 1900 1343
	COMBI	0043 1613 0537
GORENJE	TV	0592 1942 1657 0043 1423 0513 0373 0516 1249 0051
GOTRON	TV	1807
GPM	TV	0322 0359
GR 15	SAT	4326
GRADIENTE	SAT	4326
GRAETZ	see	ITT
GRAN PRIX	TV	1760 0209 0589 0557 5817
	COMBI	0371 0556
GRANADA	TV	0467 0513 0373 0427 0527 1429 1421 0540 0162 0285 0352 0147 0051 0336 0541 0473 0337 0522 1207 0359 0585 0433 1366 0471
	COMBI	522
GRANDEN	see	FORMENTI

Brand	Type	Code
GRANDIN	TV	0043 1247 0073 0424 1423 0557 0541 0513 0170 1048 1452 0209 0141 1454 0589 1070 1383 0366 1412 1740 1400 1556 1887 0097 1549 1548 1569 1971 1453 1459 0002 1290 1838 1027 0359 0352 1564 1598 0322 1568 1529 1536 0243
	COMBI	1598 0043 0034 0537 1835
GREAT WALL	TV	0513 0322
GREENPOINT	TV	1423
GRENADIER	TV	0547 0513 0359
GRONIC	TV	0513 0359
GROWING	TV	1423
GRUNDIG	TV	0351 0481 1838 0419 1147 1287 1575 1284 0549 1837 1400 1450 1491 0352 1785 0557 0540 0043 0513 1423 5886 1396 0561 1973 1454 0556 0589 0592 1057 1809 1556 1036 0579 1269 0170 1836 1412 0300 0522 1282 1014 1459 1428 1247 1051 0588 0019 0110 1760 1079 5855 5596 5973 0021 1114 1452 5900 1552 1207 5255
	VCR	481
	DVD	351
	SAT	0733 1287 0351 0585 0785 4274
	COMBI	0540 0351 1838 1598 1836 0556 0483
	HIFI	1337
	DTT	585
GRUNKEL	TV	1048 1423 0043 0513 1027 1201 0357 0484 0201 1062 1939 5256 5554 1351 0288 1046 0128 1897 0423 0325 1033 1136 1831 5242 0432 1938 0299 5508
	COMBI	0128 0357 0299
GTRONIC	TV	0513 1084
GTT	TV	0359 1420 0424 0513 1638 0043 0322
GUSTAF	TV	1716
GUTSCHN	TV	1099
GUTTA	TV	1084
GVISION	TV	6029
GXK	TV	0589 1760
H & B	TV	0043 1489 1400 0557 1788
	COMBI	1811 0043
H & E	TV	0556 0592
HAAN	TV	1450
HADOR	TV	1338
HAIER	TV	0520 0101 1900 1048 0045 1964 1156 1014 1052 1961 1719 0561 1857 1542 1779 1901 1778 0576 5811 5813 0209 1839 1001 1053 5812 5816 1423
	COMBI	0520 1961 1482 0576 1901 1887
HALIFAX	TV	0322 0359 0513
HAMA	see	HAMA DEKTI
HAMA DEKTI	SAT	4541
	DTT	4541 0686
HAMMERSTEIN	TV	0322 0359
HAMPTON	TV	322
HANNOVER	TV	1420
HANNS - C	TV	1756
HANNSPREE	TV	0032 1851 1756 0072 1773 1086
HANSEATIC	TV	0513 0554 0209 0351 1601 0557 0162 0359 1837 1942 0300 0026 0424 1739 1313 0336 0352 1638 0171 0529 0043 0555 1489 0471 1435 1207
	SAT	4541
HANTAREX	TV	0484 1957 1383 0100 1938 0513 1597 1796 1542 1514 0359 1489 1549 1117 1078
	COMBI	1514 1117
HANURI	see	LA SAT
HARMAN KARDON	HIFI	1337
HARROW	TV	1048 0043 1423
HARWA	TV	1741 1906 1277 1535
HARWOOD	TV	1638 0541 0359 0336 0549 0513
HAUPPAUCE	TV	5257 0513 0540
HAVEG	TV	0351 0373
HB	TV	0557 0043 1489 1838 1400 0073 0141 0556 0552 1837 1459 1511 0558 1435 0541 1057 0549 1739
	SAT	4321
	COMBI	43
	DTT	1057
HCM	TV	0359 0513 0424 0322 1638
HE	TV	0556 1443
HE@D	SAT	919
HEDZON	TV	0513 0540
HEIRU	TV	322
HELECTRONIC	see	FORMENTI
HELLO KITTY	TV	1048 0288 1423
HEMCO	SAT	4303
HEMILTON	TV	0561 1338
HEMSAT	TV	1178 0081 1927 0109
HENA	TV	513
HERU	TV	322
HERZ	SAT	4787
HESS	TV	1878 1346
	SAT	4541
HEVET	SAT	4541
HEXA	TV	513
HI	TV	1117
HI - TECH	TV	1338 1410
HIFI AKADEMIE	HIFI	1337
HIGH - ONE	TV	1048
HIGHWA	see	KAISUI
HIGHLINE	TV	0513 0540
HIKONA	DVD	1901
HILINE	TV	0322 0359 0415 0513
HINARI	TV	0359 0513 0322 0162 0549 0300
HIRSCHMANN	TV	424
	SAT	4288
HISAWA	TV	0424 0073 0557 0513

Brand	Type	Code
HISENSE	TV	1159 1155 1137 5206 5795 0376 1276 1294 0595 1722 0324 1571 5234 0110 1929 0373 0389 1787 1338 1119 1350 1935 1930 1931 1298 5804 5904 1921 1295 1954 5531 0352 0145 1467 1849 0359 1454 1951 1953 1048
HISHITO	see	TOSHIBA
HISONIX	TV	0424 0415 0359
HITACHI	TV	1572 1012 1048 1423 0285 1622 0043 0473 0433 0037 1501 0358 0209 1643 1685 0554 0513 1087 0147 0045 5742 1259 1109 1712 0003 1401 0467 0351 1382 0162 1601 0018 1400 0496 0558 0415 0484 1849 0051 1831 1242 0561 5832
	SAT	433
	COMBI	1423 0043 0522
HITECK	TV	595
HITEK	see	HITECK
HITSU	TV	0073 0424 0513
HIMON	TV	5833
HKC	TV	1201 5810 0201 0583 5603
HOHER	TV	1423 0043 1400 1452 0557 0366 0170 0589 1838 1048 1435 1383 1516 1437
	DVD	1146
	COMBI	43
HOME ELECTRONICS	TV	1437 0556 0043
HOME TECH INDUSTRIES	see	HOMETECH
HOMETECH	TV	0556 0557 0592 0043 1838 1423
	COMBI	556
HOMSTAR	TV	1556
HORIZON	TV	1048 1027
HORIZONT	see	PHILIPS
HORNET	SAT	4303
HORNYPHON	TV	0540 0513
HORTZ	TV	1440 0540
HOSHAI	TV	0424 0097 0043
HOSHI	TV	0043 1423
HOSPITALIERE	TV	43
HOT	SAT	4325
HOTCHIP	SAT	4303
HOTEL & PARTNERS	TV	1633
HOWELL	TV	0043 1423 0097
HUAYU	TV	1268 0051 1382 1927 0035 0534 0467 1308 0334 0406 1606 1429 0202 1712 1785 1466 1601 0557 0554 1338 1309 0585 0581 0209 0167 0373 0579 1514 1716 1950 0081 1824 1439 1023 0587 1528 1936 1530 1411 0109 0019 1303 1572 1479 0171 1507 0043 0351 0322 0145 0586 0540
	COMBI	70
HUGO	TV	205
HUMAX	TV	1755 1429 1754 1788
	SAT	4603 1754 5428 1755
	COMBI	1754 1755
	DTT	4541
HYD	TV	1450 1449 1467 1550 1794 1568 0594
	DTT	4303
HYPER	TV	0359 0513 0424 0415 0336 0322 1638 0162 0043
HYPSON	TV	0513 1423 0043 0589 0557 0541 0141 1452 0322 0170 0424 0336 0097 0209 0359 1971 1942 0552 1434 0352 0351 0073 1887 1760
	COMBI	0034 1482 1835
HYUNDAI	TV	1423 1048 0043 1017 1512 0053 1027 5446 1249 0432 1554 0589 1915 1468 1475 1792 1906 0557 1910 1783 1959 1962 1454 1851 1542 5830 1491 1450 0579 0154 1201 5328 0550 0513 1449 1740 1739 1738 1759 1568 1489 1523 1809 1383 4308 0484 1938 5426 1099 5834 1500 1400 0170 1514 1440 1502 1428 1897 1393 0376 0556 1432 1887 0145 1469 1758 1556 5516 5255 1134 1175 1529 5835 1247 5211 5984 5858 1516 1876
	SAT	4506 4541
	COMBI	0550 1542 1017
	DTT	4506
I - BOSS	TV	1847
I - CAN	see	ADB
I - INN	TV	1027
I - JOY	TV	1201 0546 1831 1027 0405 0485 0500 1242 1031 1153 0005 0188 1134 1129 0002 1781
	COMBI	0405 1831 1078
I.V.	TV	513
IBERIA	TV	513
IBEROSAT	DTT	686
ICARUS	TV	1235 5211 1178
ICE	TV	0415 0322 0513 0359 0540
	SAT	4541
ICECRYPT	SAT	5628
ICS	TV	0359 0322
ICX INTERNATIONAL	SAT	4487
ICY BOX	SAT	5257
ID DESIGN	TV	508
ID DIGITAL	TV	1429
	DTT	4910
ID SAT	SAT	4541 4910
	DTT	4910
IDEAL	TV	0097 0589
IDL	TV	485
IDTV	TV	1678
IEG	TV	513
IEKEI	TV	145
	COMBI	1440
IGS	TV	0322 0513
IJAMA	see	IJYAMA
IIN	TV	1027

Brand	Type	Code
IISONIC	TV	1951 1756 1449 1535 1512 1450
IJYAMA	TV	1975 1743 1398 1974
IKEA	TV	1143
IKUSI	DTT	5440
ILLUSION	see	ILLUSION SAT
IMAX	TV	1896
IMC	TV	0508 0325
IMPER	TV	1251 0322 0359 0513 0556 0043
IMPERIAL	TV	1420 0513 0043 1875 1491 0162 1876 0541 0016 0359 0170 1600 5842 0522 0021 1810 1891 0352 1792
	SAT	4214 4541 4127
	DTT	4541 4214
IMT	SAT	5718
IMUSIC	TV	5848
INCOBE	TV	0359 0322 0513
INDEL B	TV	324
INDIANA	TV	513
INEOS	DTT	686
INET	SAT	686
INEXIVE	TV	1048 1027
INFINITON	TV	1027 5554 1048 0484 0007 1351 1175 5844 5251
INFINITY	TV	1529 1428 1423
	SAT	5851
INFRATEX	TV	1743 0557 0541 0528 0352 0556 0359 0043 0552 0209
	SAT	785
	COMBI	1443
INGELEN	TV	0557 0558 0073 0541 0549 0351
	SAT	4321
INGERSOLL	TV	0359 0513
INGO	TV	299
INNO HIT	TV	1423 0043 0359 0513 0415 1393 1638 1282 1048 1157 5279 5953 0424 0209 0599 1215 1027 1384 0322 0352 1604 1337 1400 5788 5763
	COMBI	0043 1423 1871
INNOTECH	see	INOTECH
INNOVA	TV	1235 5632
INNOVATION	TV	0209 0541
INNOWERT	TV	1759
INOTECH	TV	1933 1897
INOV TECH	TV	0325 0576 1220 1897
INSIGNA	see	INSIGNIA
INSIGNIA	TV	5503 1558
INSPIRA	TV	556
INTENSFRANCE	TV	1423
INTER	TV	0357 0288 1136 5397
INTERBURG	TV	0322 0359
INTERBUY	TV	0359 0322 0415 0508 0513
INTERDISCOUNT	TV	0513 1313 0209 1429 0352 0351 0467 1300 1207 0140 0540 0585 0424 0541 0427 0359 0051 0528 0549 0373 0495 0339 0164 0529 0105 0586 0425 0471
	SAT	4127
	COMBI	0522 0537 0051 0064 0034 1310
INTERACTIVE	TV	0513 0540 0508
INTERECORD	see	INTERCORD
INTERFUNK	TV	0513 1420 0352 0471
INTERNAL	TV	0513 0209
	COMBI	0537 1613
INTERNATIONAL	COMBI	34
INTERSOUND	TV	0513 0471
INTERSTAR	SAT	4303
INTERVISION	TV	0513 0424 0359 0322 0209 0529 0162 0336 1638 1429 0351 1657 0471
INTREEO	TV	35
INTRON	TV	322
INVENTEC	TV	1630
INVERTO	SAT	4541
	DTT	4541
INVES	TV	1027 1201 1351 5242
INVETEC	see	INVENTEC
INVISA	TV	0351 0495 0547 0467 0322 1726 1539 0581 0339 1313 1832 0513 0209 0540 0051 1429
	SAT	4487
INWAH	TV	1638 0209
INWEST	see	OVP
IPKO	TV	5636
IPOSTAR	TV	359
IPTV	TV	410
IPUR	TV	1938
IPURE	TV	1911 1910 1937 1542 1938 1453 1966
	COMBI	1938
IO	TV	0205 0576 0007
IRIS	TV	1282
IRRADIO	TV	0513 0557 0043 0359 1400 0415 1638 0097 0561 1516 1551 0528 1469 1419 5900 0322 1525 1451 1343 0484 1048 1084 1459 1439 1269 1450 0424 1940 1577 1529 1942 1838 1882 0540 1423 0563
	DVD	1146
	COMBI	1461 0522 0359 1861 1882 0561 1443 1871
	DTT	5320 0917 1940
ISIS	TV	1048
ISKRA	TV	336
ISNATCH	DTT	5320 5440
ISOSHI	TV	73
ISPIRA	TV	556
ISUKAI	TV	0424 0513
ISV	see	IOHANSSON
ITAL	TV	1423
ITALTEL	SAT	733
ITALTV	TV	1027 0008 0432
ITC	TV	513

Brand	Type	Code
ITE	TV	415
ITL	TV	0359 0043
ITS	TV	0415 0322 0513 0359
ITT	TV	0147 0433 1423 0558 0043 0513 1400 0373 0556 0557 1837 1048 1393 1338 0563 1027 1838 5953 0141 0541 1454 5940 0008 1938 1839 1475 5242 5849 1410 0101 5375 5307 1840 0359 0322 0026 1302 1282 1973 1384 1511 1835 0508 1420 0352 0097 1849 1301 1428 1760 5658 0011 1515 1598 1556 1450 0592 0588 0336 1112 1529 1437 0589 0351 5519 1792 1459 1489 1957 1879 1514 1559 1550 1001
	SAT	0785 0791
	COMBI	0043 1938
	DTT	5440
ITV	TV	0513 0322 0540
IVO	TV	1743
IVORY	TV	1807 0556
IZAP	DTT	5320
I-ZAP	DTT	5320
IZUMI	TV	483
	COMBI	0483 0128
IADDOO TV	see	IADDOO
JAEGER	SAT	4541
	DTT	4541
JAMAJI	TV	1423
JAY-TECH	TV	484
JEC	see	TOSHIBA
JEG	TV	0043 1423
JENNY	TV	1716
JEPSEN	TV	0004 0563 1569 1555 1597 1423 0484
JERROLD	SAT	4487
JET POINT	TV	513
JINLIJU	TV	359
JMB	TV	1207 0043 0209 5886 0513
	COMBI	1598
JNL	TV	561
JOCEL	TV	0513 0556 1452 0162 0043 1338 0352 0561 0550
JOHN	TV	1716
JOHN PLAYER	TV	415
JOLLYLINE	DTT	5440 5320
JOYCE	TV	43
JPS	TV	415
JQ	TV	0594 1516 1793 1788 1587 1450 1792 1548 1400 1765 1423 0043 1789 1949 1796 1797 1794
JRC	TV	162
JTC	TV	0432 0484 1441 0563
JUBILEE	TV	540
JVC	TV	1589 0167 1470 1479 5941 1685 1048 1315 0110 1422 5651 0415 1423 0209 1140 1073 0556 5596 1282 1070 1429 0498 0097 5544 5279 1201 0548 1247 5509 1235 0043 0433 1217 1027 5446 5204 1300 5299 5348 5846 0583 5903 0549
	VCR	167
	DVD	522
	HIFI	1589
JVC TEAC	TV	498
JWIN	TV	1475
KALAI	TV	4214 1452
	SAT	4127
KABEL	TV	300
KABEL DIGITAL	TV	300
KAERN	TV	1284 0557
KAISER	TV	0513 0359 0424
KAISUI	TV	0424 0415 0073 0359 0513 0043 1638 1420 0209 1027 0070 0556 1060 0322
KALLE	TV	1716
KAMASONIC	TV	556
	SAT	4541
KAMBROOK	TV	0513 0322
KAMOSONIC	TV	556
	SAT	4541
KAMP	see	FORMENTI
KANGSLEY	see	FORMENTI
KANSAI	TV	0513 0424
KAON	see	KAON MEDIA
KAON MEDIA	SAT	4303 0781
KAOSHO	see	SAMSUNG
KAPLUS	TV	1027
KAPSCH	see	ITT
KARCHER	TV	0513 0589 0556 0359 1838 1400 0516 0557 0073 0424 1207 0162 1437 0043 0209 0322 1975 1454
	COMBI	1443
KARTEL	TV	556
KARTINA TV	TV	5740
	SAT	1169
KASAI	TV	424
KATHREIN	TV	0513 1412
	SAT	4321
KAWA	TV	415
KAWASHO	see	FORMENTI
KAYA	TV	0359 0322
K-CLASSIC	TV	589
KEN BROWN	TV	1726
KENDO	TV	0043 0051 1423 0073 0440 1249 0300 0552 0513 0359 0026 0209 1048 1450 0097 1942 1142 1494
	COMBI	43
KENMARK	TV	1103
KENNEDY	TV	0440 0579
KENNEX	TV	0043 0110 0097 1441 0513 1423 0209 0500 0188 1831 0552 0141 0557 0550 1638 1873

Brand	Type	Code
KENSTAR	TV	1949 1879 1789 0154 1587 1876
KENWOOD	TV	513
	SAT	785
	DTT	785
KENYA	TV	540
KERION	TV	513
KERMAN	SAT	4541
	DTT	4541
KERZO	TV	557
KEVION	TV	557
KEVLER	TV	557
KEY DIGITAL	see	KEY
KEYMAT	TV	1511 0550 1460 0145 1469 1541 1891 0389 1949 1879 1740 0376 1789 1794 0528
	COMBI	1424
KEYSMART	TV	0557 1400 1837 1839
KHC	TV	201
KIAMO	TV	1839 1529
	COMBI	0556 1001
KIATEL	SAT	4303
KIMAY	TV	322
KINETIX	TV	43
KING	see	KING TV
KING TV	TV	0561 0556 1338
KINCDFHOME	TV	43
KINCVISION	TV	556
KIOTA	TV	0322 0359 0415
KISS	TV	1555 0043
KISS TECHNOLOGY	see	KISS
KITON	TV	0043 1423 1249 0552 0097 0513 1942 1838 0128 1393 0359 0322 0540
	SAT	4321
	COMBI	43
KITT	TV	0322 0513
KITTEN	TV	513
KIWI	TV	101
KIYOCIN	TV	513
KLEVER	TV	557
KNEISSEL	TV	0073 0209 0105 0513 0043 1452 0541 0097 1942
	COMBI	0034 1598 0043
KOBALTRONIC	see	NEWMAR
KOBIC	TV	359
KOFF	TV	557
KOGAN	TV	1070 0110 1247
	COMBI	576
KOLSTER	TV	0513 0322
KONICHI	TV	359
KONIG	TV	1541 1511 0513 0141 0481
	SAT	919
KONKA	TV	0145 1420 1006 0415 1643 1867 1872 1415 1302 0352 0513 1657 5655 1001
KONTAKT	TV	549
KONTECH	TV	5319
KORA	DTT	5320
KORAX	SAT	0919 4787
KORPEL	TV	0513 0540
KÖRTING	TV	0043 1657 0516 0513
KOSCOM	TV	322
KOSMOS	TV	513
KOSS	TV	5658
KOTRON	TV	0322 0359 1878
KOYODA	TV	359
KRAFTCOM	TV	0007 0565
KREILING	SAT	4321
KREISELMEYER	see	KRIESELMEYER
KRIESLER	see	PHILIPS
KRISTALE	TV	513
KRUGER & MATZ	TV	6028 0110
KRYSTER	TV	1048 1351
KTC	TV	205
KTN	TV	1878 1491 1346 1376 1849
KTV	TV	1500 1910
KUBO	TV	1048
KUCCAI	TV	97
	COMBI	70
KUNFT	TV	1048 1247 1027
KUPPER	TV	43
KURO	TV	373
KWESE PLAY	DTT	5146
KYDOS	TV	1027
KYOSHO	TV	322
KYOSHU	TV	359
KYOSTAR	TV	359
	SAT	4288
KYOTO	SAT	4787
L&S ELECTRONIC	DTT	4541
L&S ELEKTRONIK	TV	557
LA REDOUTE	TV	0565 0424 0585
LA SAT	TV	424
LAMEX	TV	0351 0051 0406 0209 0373 1382 1313 1207 0528 0339 1601 0589 0540 0043 0336 1932 1857 1439 0427 0495 0557 0565 0513 1268 1606 0554 0300 1712 1366 0352 1429 0140 0558 1300 0585 0592 0481 1421 1491 0141 1980 0541 0547 0529 1411 1757 1466 1575 1657 0552 1423 0322
	SAT	0744 0785 4759 0919
LATONA	TV	1178
LAVA	TV	1516 1938
LAVIS	TV	1423
LAZER	TV	1048 1027 0528 0513 0007 1220 0043
	SAT	4541
	DTT	4541
LCE	TV	415
LEADER	TV	0359 0322

Brand	Type	Code
LECHPOL	TV	0043 0209 0336 1606 0351 0427 0552 1601 1393 0554 0529 0406 0300 1411 1712 0540 0352 1207
	SAT	919
LECSOON	TV	592
LECSOUND	TV	1454
LEDSTAR	TV	5943
LEGEND	TV	0359 0322 0513
	SAT	0785 0791
LECENT	DTT	5320
LEIKER	TV	1423 0511
	COMBI	0128 0188 0500
LEMON	SAT	4541
	DTT	4541
LENCO	TV	0513 0512 0043 0359 0484 1876 0044 0336 0162 0576 1031 0322 1809 0325 1338 1657 0085 0097 0201 1988 0366 1440 5428 5646 1401 1897 1423 1845
	COMBI	1876 0484 0188 0359 1811 1440 0325
LENOIR	TV	0513 0043 1343 0097 0359 0322 1975 1396 0141 1398 1401 1595 0336 1460 1845 1554 0424 1638 1394 1395 1397 0595 1551 0557 0528 1454 5646 1963 1743
	COMBI	1443
LENOXX	see	LENNOX
LENSON	SAT	4321 0744
	DTT	744
LENUSS	TV	1026 5229
LES 3 SUISSSES	TV	513
LEVEL	TV	1578
LEVIS AUSTRIA	TV	0513 0540
LEXIBOOK	COMBI	483
LEXSOR	TV	1741 1906
LEXUCO	TV	595
LEXUS	TV	1420 0513 0322 1491 1424 1726
LEYCO	TV	0513 0322 0359 0424
LG	TV	0334 0081 1081 0529 5522 5896 0587 1824 1023 1439 1180 0406 1606 1170 5253 5102 0547 0513 0557 1014 1857 1423 1847 1452 0141 5584 5900 0541 1932 0043 1942 1837 0561 5373 0352 0359 0336 0322 0351 0145 1459 0555 5220 0008 0528 1429
	VCR	0547 0081 0171
	DVD	0547 0081 0552
	COMBI	0034 0547 1824 0334 0557
	HIFI	5584
	DTT	547
LIAMA	TV	1975 1743
LIDAO	TV	484
LIESENKÖTTER	TV	513
LIFE	TV	1435 0359
LIFESAT	TV	0043 0209
LIFETEC	TV	0043 0209 0513 0097 1249 1435 0557 1396 0322 0589 0552 1638 1423 0558 0555 1942 1454 0359 1450 1613 0352 1455 0141 1739 1412 1142
	SAT	4541
	COMBI	1443 0043 1613
LIGHTSTAR	see	KAISUI
LINE@TECH	TV	1887 1423
	SAT	686
	COMBI	43
	DTT	686
LINEA	TV	1491
LINETECH	TV	1423
LINITRON	TV	1429
LINNEA	TV	1716
	SAT	1716
LINSAR	TV	0043 1048 1847 1423 0432
	COMBI	43
LIROS	TV	1454 0589
LISTO	TV	0043 1423 1290 1220 1048 1400 1027 1282 1604
LIVE	TV	359
LVIN	TV	5854
LIYAMA	TV	1743 1975
LLOYD'S	TV	0322 0359 0415
LME	see	PATHE CINEMA
LOBOD	TV	1027 5944
LOCATEL	TV	1854 0051 0513
LODOS	TV	1423
LOEWE	see	LOEWE OPTA
LOEWE OPTA	TV	0508 0513 1570 0400 1463 1454 0043 0352
	HIFI	1337
LOGIK	TV	1140 1815 0561 1577 0097 1798 1048 0043 1899 1412 5370 0513 1941 1398 1420 1467
	COMBI	1815
LOGISAT	SAT	4288
	DTT	4288
LOGIX	TV	0097 0513
	SAT	4303
LORENZEN	SAT	4288 4541
	DTT	4288
LOTTA	TV	1716
LOVE	see	ELBE
LS ELEKTRONIK	see	LS ELEKTRONIK
LS ELEKTRONIK	TV	0557 1435 1837 1423 1383
	SAT	4541
LTV	see	OCEANIC
LUMA	TV	0440 0043 0209 0513 0359 0352 0540
LUMATRON	TV	0043 0440 0513 1788
	COMBI	1884
LUPUS	see	ANKARO
LUXER	COMBI	1443
LUXMAN	TV	561
LUXMAY	TV	0513 0540

Brand	Type	Code
LUXOR	TV	0433 1423 0558 0043 0147 0162 0556 0373 1048 1643 1434 1207 0513 0592 1847 0352 1393 1249 0589 0285 5856
LUXOR BV	see	LUXOR
LUXTRONIC	TV	1423 0043 0592
LWGBO	PC	547
LYOTRON	see	LG
MDC	TV	1638
MSAT	SAT	5304
MACAB	SAT	0785 4148
MACROLUX	TV	1452
MACTECH	TV	322
MACTEP	SAT	919
MADISON	TV	0513 0541 0540
MADISON FIELDING	see	MADISON
MAESTRO	SAT	4321
MAG	TV	0205 1976 5372 5295 1831 1857
MAGASIN	TV	1423
MAGAVOX	see	PHILIPS
MAGIC	SAT	919
MAGIC BOX	SAT	4303
MAGNA	TV	1384
MAGNADYNE	TV	0043 0513 0359 1420 0548 1027
MAGNAFON	TV	0513 0043
MAGNASONIC	TV	0513 0359
MAGNAVOX	TV	1832 1823 1207 0513 1830 0471 1558 1852
	DVD	513
	TV	0513 0322
MAGNUM	TV	0557 1454 0589 0556 0141 0043 0513 1500 1740 1907 1505 0209 1420 0359 1638 1400 1788 1731 1452
	COMBI	1461
MAJESTIC	TV	0432 0484 0583 0201 1343 0357 0110 0288 1201 1595 1978
	DVD	288
	COMBI	0484 0432 0583 0357 0201 0110 0225 1978
MANDI	TV	589
MANDOR	TV	322
MANESTH	TV	0513 0337 0541 0300 0322 1207
MANHATTAN	TV	0043 1423 0097 0513 0359 1048
	SAT	4166 4303
MANTA	TV	1027 5426 5554 1201 1441 1048 1175 5302 1117 1235 5318 5945 5607
MARANTZ	TV	0513 0528 1382 1459 0471
	VCR	376
	DVD	1516
	HIFI	1337
MARCA CANARIA	TV	36
MARECH	TV	513
MARK	TV	0336 0513
MARK LEVINSON	see	MARK
MARSHALL	TV	0359 1343
MARYUANA	TV	1207
MASCOM	TV	0589 1454 1938 0558 0513 1838
	COMBI	1461 1443
MASTEC	SAT	4541
MASTER	TV	0008 1235 1201 1027 0583 0556 1949 1387 5247 1275 1505 1536 1511 1789 1175 1048 0449 0488
MASTER SAT	see	MASTER
MASTER VIDEO	see	DAEWOO
MASTERS	TV	0541 0424 0352
MASUDA	TV	0513 0322 0300
MATCH ITALIA	TV	0513 0322 0359
MATEL	TV	1971 1410
MATRIX	TV	1400 0557 1837
MATRIX AUDIO DESIGN	see	MATRIX
MATS	TV	1716
MATSUI	TV	5886 0373 0351 0300 0359 0549 0162 0336 0557 0513 1743 1815 0592 1423 1207 0337 0415 0170 0589 1249 0043 0201 0556 0051 1412 0527 0322 1643 0581 0352 1976 1831 1044 1452 1598 1577 0145
	COMBI	1598 0043 0561 1423 0201
MATSIKA	TV	322
MATSUVIANA	TV	528
MATSUYAMA	TV	513
MAX	TV	589
	DTT	4506
MAXAM	TV	0359 0322
MAXDORF	TV	1084 0561 0322 1798
MAXELL	TV	0359 0424 0043
MAXIM	TV	0589 1454
	COMBI	1443 1461
MAXIMAL	TV	162
MAXIMUM	SAT	4541
	DTT	4541
MAXON	TV	359
MAXPLUS	SAT	4506
MAXTON	TV	1249
MAXVIEW	SAT	4288
MAXWELL	TV	0513 1807 0595
MAZA	see	ZAPP
MB LINE	TV	0322 0513
MBOX	SAT	5324
MC MARREL	TV	1484
MC MICHAEL	see	PHILIPS
MC PERSON	TV	1432
MCE	TV	0359 0322 0425 0513
MCM	TV	0359 0424
MDC	TV	513
MEC	TV	322
MECOA	TV	513
MEDIABOX	SAT	785
MEDIALIFE	TV	1113 0584

Brand	Type	Code
MEDIALINE	TV	1514
MEDIASAT	SAT	785
MEDIASCREEN	TV	0513 0322
MEDIASET	SAT	785
	DTT	5083 0917
MEDIASONIC	TV	513
MEDIATOR	TV	0513 1249 0471
MEDION	TV	0043 1048 0557 0209 0513 1435 5214 1423 1249 1396 0097 0589 1220 1942 1638 0552 1455 0558 0352 1412 1450 1454 5762 0561 0423 1598 1837 5886 0325 0576 5606 5248 1207 1896 0541 1489 1739 0484 1383 1983 1760 1831 0592
	DVD	334
	SAT	4541 4288
	COMBI	1443 0043 1598 1461 0483 0561 1424 0423 0399 1220 5762
	DTT	4541
MEGA	TV	1731 0556 0073 1505 0550
	DTT	5440
MEGAS	TV	73
MEGASAT	TV	1220
	SAT	686
	DTT	686
MEGASKY	SAT	4541
MEGASOUND	DTT	5440
MEGASTAR	SAT	4303
	DTT	4541
MEGATECH	TV	513
MEGATONE	TV	1657 0513
MEGATRON	TV	547
MEGAVISION	TV	359
MECHA	TV	513
MEI	TV	1048 1423
MEIRAZ	TV	513
MEISTER	TV	0554 1657
MELBOX	see	CLARIVOX
MELCHIONI	TV	0557 1400 1551
	SAT	919
	COMBI	1461 1443 1861
	DTT	919
MELECTRONIC	TV	0513 0147 0351 0209 0359 1638 0433 0588 0540 0508 0558 0587
	SAT	0147 0433
MELICONI	TV	1048
MELITA	SAT	4487 5522
MEMOREX	TV	322
MEMORY	TV	1423 1961
MEMPHIS	TV	0322 0359
MEO	SAT	4849 0440
MERCURY	TV	0322 0359 0513 0471
METEOR ELECTRONIC	see	METEOR
METRONIC	SAT	0919 4288
	COMBI	43
	DTT	0744 0202 4541
METZ	TV	0338 1806 0351 0043 5764 5763 0513 5987 5994 0097 1807 0359 1301 0424 1269 1529 0036 1282 5381 5970 6007 0552 1809 0561 0011 5255 0427 0322 0366 1973 5550 0399
MG ITEX	DTT	1419
MCA	TV	0513 0322 0547
MCAON	TV	322
MICRO-EX	see	MICRO-X
MICROMAXX	TV	0043 0552 0513 0097 0557
MICROMEGA	HIFI	1337
MICROSKY	SAT	919
MICROSPOT	TV	1412
MICROSTAR	TV	1435
MICROTEK	TV	0513 0359 0561 1084 1127
MICROYAL	SAT	4541
	DTT	4541
MIIA	TV	0485 5987
MIKA	TV	359
MIKOMI	TV	0043 1423 1400 1393
MINATO	TV	0589 0513
MINERVA	see	GRUNDIG
MINERVA FRANCE	TV	549
MINISTRY OF SOUND	TV	1423
MINOKA	TV	513
MIRAGE	TV	1400
	SAT	686
MIRAI	TV	1743 1039 5625
MISAKAI	TV	1558
MISC	TV	1598
MISTRAL	see	THORN
MITASHI	TV	1027
MITCHELL & BROWN	TV	1048
MITSAI	TV	1048 1423 0043 0589 1459 1678 1247 0541 1036 0336
MITSUBISHI	TV	0527 0425 0043 0513 0209 0359 1885 5765 0547 0147
	VCR	527
	COMBI	0522 0537
MITSUBISHI ELECTRIC	see	MITSUBISHI
MITSUMI	TV	300
MITSURI GENERAL	TV	0105 1657
MITSUSIMA	TV	0513 0322
MIVAR	TV	0408 0105 0485 0110
MIYOTA	TV	0595 1343 1078
MIYUKI	TV	322
MKC	TV	1419 1343 1551 1990 0557
MKE	SAT	4288
	DTT	4288
MOBILE TV	TV	0043 1048

Brand	Type	Code
MONDIAL CASA	TV	1556
MONEUAL	TV	1351
MONTEREY	SAT	4321
MOONSTAR	SAT	4541
MOOVE	TV	0357 5639 0484 5939
MORAVA	TV	0043 1437 1207 1142
MORGANS	TV	513
	SAT	4288
	DTT	4288
MOSAIC	TV	0097 0043 0513
MOTEVA	TV	495
MOTION	see	UHER
MP	TV	1551
MPMAN	TV	0488 0110 1551 0484 0432 1220 1387 1840 1201 1494 5251 1027
MT LOGIC	TV	1400 0557 0484
	COMBI	1883 1835 1424 0483
MTC	TV	1657 0508 1884 0336 0008
MTV	TV	1835
MULLER	see	MULLER & KOCK
MULLER & HAUPT	see	MULLER & KOCK
MULLER & KOCK	TV	0011 5780 5279
MULTICHOICE	SAT	4647 4649
	DTT	917
MULTITECH	TV	0513 0557 0359 0336 0209 0141 0043 1657 0589 0097 0322 0424 0541 1454
	COMBI	359
MURPHY	TV	1423
MURYUANA	TV	1207
MUSE	TV	5504 5519
	DVD	5519
MUSIKLAND	TV	0513 0540
MUSTEK	TV	1813 0507
MUTECH	SAT	4541
MVISION	COMBI	1979
MVPOWER	see	MYPOWER
MXONDA	TV	1897
	COMBI	1482
MXT	TV	8
MYOTA	TV	1343
MYRIA	TV	0043 1423
MYRYAD	TV	513
	HIFI	1337
MYSKY	SAT	4594 4749 4603
MYSTERY	COMBI	5775
MYSTRAL	TV	1452
MYTV	TV	488
NABO	TV	1048
NAD	TV	547
NAGOYA	TV	162
NAIKO	TV	0589 0513 0541 1420 0336
NAKAFUJI	TV	70
NAKAMURA	TV	513
NAKASHI	TV	513
NAKASUMI	TV	595
NAMSONIC	TV	359
NAMSUNG	TV	359
NAONIS	see	SELECO
NARITA	TV	0322 0547
NASSA NAGEL	see	ENGEL
NAVON	TV	1048
NEC	TV	0472 1475 0359 1623 1245 0493 5757 1690 1607 1629 1336 1507 1556 1630 5758 1536 0513 0554 1597
	VCR	472
	COMBI	1911
NECKERMANN	TV	0513 0351 1313 0352 0359 0209 0467 0540 0043 0300 0555 0440 0588 0508 0140 0167 0162 0585 1207 1300 0170 0337 0339 0516 1638 1420 0541 0557 0471
NEI	TV	0513 0162 0541 0432 0043
NEO	TV	1048 1027 0145 0556 1849 1850 0043 1423 1792 1100 0557 0550 0561 1872
	COMBI	556
NEOM	TV	1571 1597 1423
	COMBI	43
NEON	TV	0594 1833 5643
NEOTION	SAT	4541
	DTT	4541
NEOVIA	TV	1514 1542 1383 1516 1568 1459 1450 1792 0556 1301 1569 1453
	COMBI	1514
NEPTUN	TV	513
NESX	TV	1526 1529 1536
	COMBI	449
NET +	see	NET
NETSAT	TV	513
NETVIL	see	NETVILLE
NEU	see	NEUF TELECOM
NEUF TELECOM	TV	209
NEUFUNK	TV	0043 0557 0541
	COMBI	43
NEUHAUS	SAT	4541
NEULING	SAT	4288 4541 4303
	DTT	4288
NEULINK	SAT	4541
NEVIR	TV	1027 5508 1423 0306 1235 1062 1633 0500 5426 0201 1831 1351 5307 0225 5641 1384 5946 1175 1873 0322 1048 5251
	COMBI	0306 1423
NEW GOLDVISION	see	SONOKO
NEW STAR	SAT	919
	DTT	919
NEW VISION	TV	528
NEWELL	TV	513
NEWMAR	TV	513

Brand	Type	Code
NEWTECH	TV	0513 0359
NEWTRON	TV	1343
NEXIUS	TV	0556 0589 1423 0588 0592 5886 0043 0557 1393 1452
NEXT	TV	1400 1604
	SAT	4303 0686
	COMBI	0043 1078
NEXT CONCORDE	TV	359
NEXTIER	TV	1518 1760
NEXTSTAR	SAT	4303 0686
	COMBI	43
NEXTVISION	SAT	4303 0919
NFREN	TV	1555
NGM	TV	5242 5546 5328
NIBELS	TV	1384
NICAMAGIC	see	FORMENTI
NIKE	TV	513
NIKKAI	TV	0513 0337 0162 0141 1638 0424 0541 0043
NIKKEI	TV	0043 1423 1938 0513 0589 0514 1048 0426 0322 0097 1469 1400 1966 0053 1537 1587 1949 0557 1449 0449 5586 1454 1550 1838 1839 1789 0101 0484 1069 1975 1797 1865 1837 1031 0299 0141 0337 1467 0170 0556 1594 0359 0352 1578 1511 1529 1835 0286 0201 1393 1957 1384 5103 1247 0209
	COMBI	1835 1461 0556 1938 0299 1069
	DTT	5320
NIKKO	TV	0513 0541 0547 0359
NIKOJ	TV	0589 1423 0541 0043 1048
	COMBI	1443
NILELINE	TV	589
NINBUS	TV	516
NIPPON	TV	1376
NISATO	TV	1726
NISHI	TV	359
NOA	TV	5446
NOBEL	TV	1440
NOBLEX	TV	0540 0415 0359 1539
NODIS	TV	1027 5242
NOKIA	see	ITT
NONAME TV SETS	TV	43
NOOS	SAT	744
NORDMENDE	TV	1423 1201 1235 0154 1027 1275 0589 1040 0043 1876 0588 1435 0557 1587 1949 0051 1428 1400 1541 5756 0164 0556 1514 1868 4308 1048 5241 1879 5886 1756 0026 5211 1542 1489 1739 1247 5213 5983 1452 1397 1396 1469 1814 1484 1249 1789 1398 0583 5554 5999 0424 1743 1207 1454 1401 1395 1938 5762 1529 5607
	SAT	154
	COMBI	0556 0051 0043 1396
NORDTON	TV	97
NORDWAY	TV	1657
NORFOLK	TV	541
NORIKO	TV	589
NORIMEX	TV	359
NORKABEL	SAT	4487
NORM	see	NORMN
NORMN	TV	513
NORMANDE	TV	0359 5772 0557 5769 0513 0561
NORMEREL	TV	0513 0540
NORTEK	TV	0097 0043 0513 0141 1833
NORTHERN STAR	TV	1178
NORTHSAT	TV	97
NORTLINE	COMBI	1424
NORTON	TV	0359 0424
NORWAY	TV	1657
NOSE	TV	1343
NOVA	TV	0359 0513
	SAT	6034
NOVAK	TV	0513 0540
NOVASAT	SAT	4127 4214
NOVATRONIC	TV	0513 0359 0322 0209 0541
NOVITA	TV	0053 1915 0043
NOW TV BY SKY	SAT	5146 5724
NOWTV	SAT	4476
NPG	TV	1247 5647 1070 0432
	DTT	686
NTC	TV	1338
NU -TEC	TV	1415 1809 1807 0561 1454 0373
NUCLEAR	see	PRANDONI
NUETEC	see	NU -TEC
NUMERICABLE	SAT	785
NVISION	SAT	4303
NYTRO BOX	SAT	686
O GENERAL	TV	359
OK LINE	TV	0557 0043 0589 0556 0592 1400 1437
OCEAN	TV	0008 5948
OCEANIC	TV	0433 0147 0373 1048 1027 0008 5446 0432 1351 0162 1792 5211 0552 0352 1554 1514 1201 1598
	SAT	0785 4506
OCEANS	TV	359
OCTAL	SAT	744
OCTUS	TV	1338 1849
ODEON	TV	0513 0322 0359 0471
ODYS	TV	0498 0483 0101 0085 0007
	COMBI	0085 1001
OEC ELECTRONIC	TV	1494
OK	TV	1247 1048 5596 1423 1070 1140 1114 0583 5586 5947 0484 1027 5763 5764 1220 5204 0599 1400 1838 0548 1201 5987 1242
	DTT	5320
OKANO	TV	0513 0359
OKEAH	TV	1556

Brand	Type	Code
OKI	TV	1423 1400 0043 1247 0599 1048 1838 0423 1454 0576
	COMBI	0043 1423 0599 0423
OLEVIA	TV	5928 5948
OLIDATA	TV	1915 1911 1450 1551
OLIMPIA	TV	1423
	SAT	919
OLMAL	see	ALBIRAL
OLYMPIC	TV	0359 0424
OMAX	SAT	4303
OMEGA	TV	0415 0322
ONCEAS	TV	359
ONDIOLA	TV	513
ONIDA	TV	513
ONIEL	TV	359
ONIX	TV	484
ONIN	TV	1400 1423 1838 1868 0209 1897 0043
ONO	SAT	4632
ONWA	TV	0415 0070 0097 0322 0513 1048 1420 0556 0359 1337
	SAT	4541 4303
	DTT	4541
OPENBOX	SAT	919
OPENSAT	SAT	686
OPENTEL	TV	1451
OPENMEW/HD	SAT	5291
OPERA	TV	1400 0513 1788 0043 0322 0557 0359
	COMBI	1897
OPTEX	SAT	4321 1422 5291 0919 4288 4303 4990
	DTT	919
OPTICUM	SAT	4541 0319
	DTT	4432 4541
OR - ON	TV	0513 0322 0359 0424
ORA	SAT	4303
ORANCE	SAT	744
ORAVA	TV	0513 0541 1850 1502 1048 1027 1844 1423 0043
	COMBI	550
ORBISAT	SAT	919
ORBIT	TV	1657 0513
	SAT	4541
ORBITECH	SAT	4214 4127 4541 4321
	DTT	4541 4214
ORBITER	TV	1657
ORCHID	SAT	686
OREON	TV	424
ORIENT	TV	0556 0359
ORIMA	TV	1048
ORION	TV	0300 0513 1422 5886 0557 1814 1598 0588 0043 0170 0471 0589 1452 1207 1073 0352 0555 5521 5248 0322 0556 1837 1423 0359 1739 1450 5523 0162 1741 0415 1412 1489 1396 1607 1048 0141 1975 0026 1906 1247 1820 1440 0540 0472 1251 1550 0541 1394 1849 1601 1556 1070 1400 1157 1838 5428
	COMBI	1598 0043 5747 5428 1482
ORION (HUNGARY)	TV	0043 0513 0589 0162 1870 0415 0322 1422 1587 0471 1837 0592
ORION TELEKOM	TV	1169
ORLINE	TV	0513 0540
ORMOND	TV	0043 0097 0513 0540
ORSON	TV	0322 0359 1849
ORSONIC	TV	0322 0359
ORSOWE	TV	322
OSAKA	see	SHORAI
OSAKI	TV	0513 0322 0043 1207 0162 0415
OSCAR	TV	0513 0373
OSIO	TV	513
OSUME	TV	513
OTAKE	TV	300
OTAVA	TV	1437 0557
OTF	TV	0513 0556 1942 0471
OTHER LINE	TV	0513 0351 0300 0508 0336 0162 0471
OTRUM	TV	147
OTT	SAT	5324
OTTO VERSAND	TV	0351 0513 1429 1313 0140 0352 0300 0427 1300 0467 0508 0585 0586 0051 0359 0555 0209 0339 0162 0415 0336 1942 0540 0522 0529 1310 0424 1207 1423 1760 1463 1837 0554 0433 0541 1638 0105 0557 0471 1400 0423 1452 0535 0043
	SAT	4214
	COMBI	1598
OUTWARE	TV	43
OVHD	SAT	5291
OVP	TV	0513 0511
OXYGEN	TV	0101 0008 0528
PACE	SAT	0733 5428 4594 0785 4749 4274 4603 4618 4554 4990 4647 4617 4649 0529
PACIFIC	TV	0043 0557 5886 0592 1556 0352
	VCR	1598
	COMBI	0043 1598
PACKARD BELL	TV	1673 1516 1722 1494 1606
PALCOM	SAT	919
PALLADIUM	TV	0513 0209 0351 1207 0555 0588 0552 1454 0540 0589 0359 1837 0508 1423 1760 0043 0170 0352 0162 1249 0440 0471 1420 0557
	COMBI	1443
PALSONIC	TV	0576 1220 0511 0008 0484 0319 0423 1807 0493 0479
PALSONIK	TV	0322 0513 0359
PANACHE	TV	1400 1838
PANAGOLD	TV	359
PANAMA	TV	0513 0322 0359 0516
PANASHIBA	TV	359

Brand	Type	Code
PANASONIC	TV	0534 1122 1411 1712 0427 0535 1079 1431 1429 1048 1337 1685 0513 1785 6005 0351 0528 6006 0359 0473 1137 1103 0352 1773 6004 1313
	VCR	427
	DVD	1712 0534
	SAT	733
	COMBI	1712 0427 0534
PANAVISION	TV	0513 0322 1423
PANAVOX	TV	0359 0513 0424 0579
PANDA	TV	5785
PANORAMA	TV	0359 0322 0513
PANORAMIC	TV	5900 0432
PANTAX	TV	1440
PAOLO	TV	507
PARROT	TV	351
PATHE CINEMA	TV	1657
PATHE MARCONI	see	THOMSON
PATRIOT	TV	352
PAUSA	TV	359
PAY	TV	1880
PBL	TV	373
PCM	TV	0513 0541
PEACOCK	TV	0513 1489 0471
PEAQ	TV	1048
PEEKTON	COMBI	0306 0484
PENTAFILM	DTT	5246
PENTUS	TV	1741
PEONY	TV	0527 0425
PERDIO	TV	0513 0300 0359
PERFEKT	TV	513
PETRIK	TV	5636
PEYSS	SAT	4787
PHILBIX	see	DESMET
PHILCO	TV	1420 0513 0162 0351 0359 0541 0516
PHILIPS	TV	0352 0513 0540 1303 1207 0586 0585 0479 1097 1268 1366 1048 0584 0081 1830 0522 0051 1804 0351 5326 0043 1561 1053 0170 1760 1832 1642 1423 5980 0209 1963 1383 1313 0508 1452 5886 1079 5349 6017 0440 1451 0592 4309 1393 0471 1466 1536 5327 5377 5241 0337 6009 6010 5900 0145 0541 4127 0785 1838
	VCR	522
	DVD	0352 0513 1268 4127 1303
	SAT	0785 4127 4309 0585 0733 0540
	COMBI	0522 1463 1207 1443 0540 0201 4127
	HIFI	0513 1303
	DTT	4309 4432 0043
PHILIPS (F)	see	PHILIPS
PHOCUS	TV	1400 0557 1435 0592 1837
	COMBI	1836
PHOENIX	TV	0513 0541 0043 0162 0471
PHONOLA	see	PHILIPS
PHONOTREND	TV	1550
PIONEER	TV	0513 1508 0589 0170 1823 0415 0322 0471
	SAT	0785 0043
PIONIER	TV	541
PIXEL	TV	1865
PK SAT	see	HIRSCHMANN
PLANET	TV	0589 0556
PLANTRON	TV	0359 0322 0513
PLASMATECH	TV	1383
PLATINIUM	TV	1556
PLAYDOR	TV	322
PLAYSONIC	TV	0557 1837 1400 0541 0513 0051 0141 1838 1494
	COMBI	43
PMB	SAT	4541
	DTT	0917 4541
POINT OF VIEW	TV	1410
POLAR	TV	1523 0513
POLARIS	TV	1506
POLAROID	TV	1838 0432 1831 5286 1048 1976 1351 1979 5211 1837 1201 5426 5784 1604 1235 5271 5251 5246 5903
POLLIN	SAT	4541 4288
	DTT	4541 4288
POLSAT	SAT	744
POP	TV	0322 0359
POPAY	TV	0322 0359
POPPY	TV	0359 0322
PORTLAND	TV	0209 0513 1638 0471 0359
POSTAR	TV	359
POWER SKY	SAT	919
POWERPOINT	TV	0549 1452 0145 0110 0513 1207 1884 1897
	COMBI	1897
PRAGA	TV	1113
PRAGMA	see	PRAGMA DIGITAL
PRAGMA DIGITAL	TV	1400
PRAKTIK	TV	0592 0556
PRANDONI	TV	0043 1434 1207 0359 0162 0352 0513 0170 0097 0592
PRE LUNA HOTEL	TV	1578
PRECISION	TV	1731 5900
PREISNER	SAT	4288 4541
	DTT	4541 4288
PREMIER	TV	0579 1251 1112 0322 1485 1452
	SAT	4787
PREMIER TECH	TV	5375
PREMIERE	SAT	4214
PRESTIGE	TV	484
PRESTIGIO	TV	1489
PRIMA	TV	0322 1741 0043 0359
PRIMA ELECTRONIC	see	PRIMA
PRIME	TV	0043 1824 1440

Brand	Type	Code
PRIMUS	TV	1207
PRINCE	see	PRANDONI
PRINCESS	TV	0589 0359 0557 1400
PRINCETON	TV	1048
PRINSTON	TV	1048 0141
PRINZ	TV	0513 0043 0556
	COMBI	43
PRO 2	TV	0489 0589 1760
PROCYON	see	PHILIPS
PROEL	TV	513
PROFESOR	see	PROFESSOR
PROFESSOR	TV	1938 0513 0471
	COMBI	1938
PROFEX	TV	0359 0162 0513
PROFI	TV	359
PROFILINE	TV	0043 0359 0513
PROFILO	TV	0589 1454 0513 1942 0162 0170 0585 0051 1937
	SAT	589
	COMBI	1443 1461 1938
PROFITECH	TV	513
PROFITRONIC	TV	513
PROLINE	TV	1423 0043 0051 1247 0554 0209 0170 1450 1887 1393 5211 1601 1643 0541 0557 1412 0432 1027 0513 0555 0300 5886 1103 1178 0299
	COMBI	0043 1423 1835
PROLITE	TV	1743 1398
PROLUX	TV	0589 1849
PRONEXT	SAT	4303
PROSCAN	see	RCA
PROSONIC	TV	1838 1423 1400 0043 1925 1036 1432 0540 0513 1638 0557 1048 0415 1440 0036 1536 1437 0576 1572 0512
	COMBI	0511 0036 0512 0576 1876
PROTECH	TV	0513 0043 0097 1942 1420 0336 1450 0351 1548 0540 0359 1638 0322 1449 1511
PROTEK	TV	1548 1450 1449 1511 1572 1851 1831 1577
PROTON	TV	547
PROVIEW	TV	1033
PROVISION	TV	0556 0513 0209 1207 1434 0522 1437 0322 0359 0352 0557
	COMBI	0556 1443
PROVISION - ISR	see	PROVISION
PVISION	TV	5550 1489 1475 1792 1623 1760 1911 1423 1459
PYE	see	PHILIPS
Q	COMBI	1938 1873
Q - COMBI	COMBI	1938 1873
Q - MEDIA	TV	0002 0599 0201 0576 0225 0325 0484 1056 0449 5551 0100
	COMBI	0225 0188
QBELL	TV	0500 5103 0205 0053 0432 1351 5107 1387 0201 1915 5446 1851 5248 5242 1201 0583 5259 1673 5903
	COMBI	500
	DTT	4432
QBOX ONE	see	QBOX
QCOMBI	COMBI	1938
QILIVE	see	QILIVE TV
QILIVE TV	TV	1048 1423 1027 5216
QONIX	TV	0484 1546 1966 1550
	COMBI	1482
QUADRAL	TV	1313 1420
QUADRICA	TV	0584 0147 1722
QUADRO	TV	0043 1048 0552 0500 0579 1795 1423 1731 0556 1117 0550 1352 1247 1505 5944 1741 1633 1879 1337 1924 1925 1410 1420 1988 1027 1112 1502 1393 1302 1249 0205 1070 1351
	SAT	4321
	COMBI	0043 1938
QUART	TV	556
QUARTEK	TV	1597
QUASAR	TV	1383 0359 1343 0100 0162 1796 1938
	COMBI	1938
QUEEN	TV	0513 0359 0322
QUEENFIDELITY	see	DAEWOO
QUELLE	see	UNIVERSUM
QUIGG ELECTRONICS	COMBI	357
R LINE	TV	513
RADIALVA	TV	0513 0540 0105
RADIO SHACK	TV	0513 0547
RADIO STEINER	COMBI	537
RADIOLA	see	PHILIPS
RADIOMARELLI	TV	0513 0359 1420 0263 1638 0288 0500
RADIOTONE	TV	0513 0359 0336 0322 0043 0589 0352 1207 1657 1638 0541 1423 0097
RAFENA	see	BRUNS
RAINBOW	see	PACE
RANK / RBM	TV	162
RANK ARENA	TV	1607
	COMBI	5751
RAYMOND	TV	352
RCA	TV	0051 0513 0547 1251 1539 5603 0583 5749 5947 1201
REALISTIC	TV	547
RECOR	TV	0513 1420 0508 0043 0540
RECTILIGNE	TV	513
RED STAR	TV	0589 0556
	COMBI	1443
REDDER	TV	105
REDIFFUSION	TV	0427 0586 0351 0495 0540 0051 1313 1207
	COMBI	522
REDLINE	SAT	4541 4651

Brand	Type	Code
REDO	TV	359
REDPOINT	TV	549
REFLEX	TV	0513 0043 0097 0552 0540 1942
	COMBI	1443
REFLEXION	TV	0366 0576
	COMBI	0484 0366
REGAL	TV	0043 1393 0170 0550 1423
	SAT	4321
	COMBI	1423 0043
REGENTE	TV	359
RELISYS	TV	1383 1401 1759 1515
RELLOK	see	RELOOK
RENDER	TV	0557 0100 1949 1529 1078 1789 1511 1873 1587 1879 1412 1469 1966 0550 1428 1400 1450 1423
REOC	TV	0557 1837
	COMBI	1613
RESTEK	HIFI	1337
REVEZ	SAT	686
REVOX	TV	0508 0513 0540 1337
REX	see	SELECO
REX ELECTROLUX	TV	1276
RFT	see	BRUNS
RHINEX	TV	561
RICOH	TV	0513 0540
RINEX	TV	1798
RITAR	DTT	4541
RM 2000	TV	0043 0513 0097 0552 1942 0540
ROADSTAR	TV	0557 0043 0359 1453 1400 1837 0513 0097 1343 1469 1423 0170 1207 0141 1559 0541 0555 1435 0352 0552 1525 0589 0322 0556 0528 0140 1451 0336 1789 1836
	SAT	785
	COMBI	0043 0034 1598 0537 0359 1424 1883 0070 0561
ROBERTS	TV	352
ROBOTRON ELECTR	TV	0336 1207 1429 0352 0322
RODEX	TV	0359 0415 0513 0424
ROKU	SAT	5146 5724 4476
ROLLMASTER	see	ROLMASTER
ROLSEN	TV	1523 1489 0529 1850 1571 1606 0550 0513
ROMTELECOM	see	ROMTELECOM DOLCE
RONYX	TV	1849
ROSE	SAT	5168
ROSE&HOLIET	TV	373
ROSITA	TV	359
ROWA	TV	0513 0322 0359 0170 0043 0097 0556 0424 0548
ROWEL	see	ROWELL
ROYAL	TV	0322 0513 0424 0359 1420 0556 1849 6000
ROYAL LUX	TV	0556 0322
RUBIN	TV	513
RUEFACH	see	LENCO
RUKOPIR	TV	0513 0540
S - FAIT	see	FAIT
S - FAIT PLS	see	FAIT
S & P	TV	0592 0513
SAB	TV	43
	SAT	4303 0686 4910
SABA	TV	1423 0051 1048 1070 1247 5596 0043 0513 1027 5586 0589 0557 1494 1114 0359 0162 0484 1942 1838 0164 0548 1422 5830 0592 0585 1939 1606 0423 1435 0101 0243 5568 0351 0583 0537 0488 1685 0201 1469 5446
	VCR	0051 0537
	DVD	51
	SAT	589
	COMBI	0537 0051 1443 0243 0043
SABRE	see	PACE
SAGA	TV	1938 1423
SAGEM	TV	0073 1552 1735 0513 1014
	SAT	744
SAGEMCOM	see	SAGEM
SAISHO	TV	0300 0359 0373 0513 0322 0170 0557
SAIVOD	TV	0589 0244 0043 0513 1423 0511 1136 1027 0540 0484 0325 1062 0201 1441 5614 0423 0026
	COMBI	1443 0128
SAKAI	TV	0300 0359
SAKEO	TV	359
SAKIO	TV	0322 0359
SAKURA	TV	0547 0359 0557 1249 0073
SALORA	TV	0433 0558 0147 1938 1048 0162 0373 1760 1423 0556 1838 0101 0513 0592 1434 1027 0170 0589 1643 1207 1847 0043 0507 0484
	COMBI	1443 1938 1838
SAMBERS	TV	0100 1938
SAMPO	TV	0513 1489 0471
SAMSUNG	TV	1927 0035 1382 1113 5285 1950 0565 0528 0513 1716 0359 5552 1348 0043 1356 0064 1405 0467 6031 1495 0209 1338 0322 0034 0352 5262 5866 1657 0540 1112 5881 5290 0594 0170 0547 1027 1048 0585 5284 0529
	DVD	1382 1113 0035 0528
	SAT	4749 4618 0733 0529 4274 4594 0744 0785 5083 1927
	COMBI	0064 1716 0528
	HIFI	1382 1113
	DTT	5083
SAN MARCO	TV	288
SAND	TV	170
SANDOR	see	OCEANIC
SANDRA PORTO	TV	1716
SANDSTROM	TV	1276 1140
SANG	TV	0557 0541 0141
SANITRON	TV	1423 0557 0043

Brand	Type	Code
SANKYO	TV	513
SANSUI	TV	0513 0561 1523 0243 0415 0322 0043 0540 0359 1539 0546 5231 0070 1606 1831 1529 1933 1428 1396 1559 0263 0029 1942 0097 0557 0588 1423 1469 1489 1853 1807 1782 1556 1966 1971 1201 0424 0373 0541 1340 1587 1343 1440 0579 1934 1511 0589 1243 1809 1454 1789 0008 1880 1677 0011 1099 1633 0225 0449
	SAT	4541
	COMBI	0243 0449 1883 1874 1811
	HIFI	1337
SANTON	TV	359
SANTRONICS	TV	1428 1523
SANWA	TV	373
SANYO	TV	0373 0043 1423 1048 0493 0589 0513 1018 1657 0145 0557 1805 1249 0359 1393 1598 5900 1539 1837 5834
	COMBI	0043 1423
SANYOSAT	SAT	4303
SAR	TV	513
SAT	SAT	733
SAT - STAR	SAT	919
SAT +	SAT	4506
SAT ITALIA	see	WISI
SATFORCE	SAT	919
SATPLUS	SAT	4506
SATUM	see	URANYA
SAVE	TV	0513 0359 0322 0162
SAVILLE	see	ORION
SBR	see	PHILIPS
SC	SAT	4288
	DTT	4288
SCEPTRE	TV	5245
SCHAUB LORENZ	TV	0557 1423 0433 0513 0043 1400 0008 1048 0556 1838 0359 1837 0589 0514 0101 1865 1475 1839 0484 0097 0552 0541 0426 0400 0336 1459 1511 1731 1840 1938 0449 0373 0322 1638 1469 1514 1207 0026 1541 1781 1069 0162 0508 0424 1393 1556 1450 1550 0376 1454 0555 1486 1057 1068 0147 0592 1489 0352 1792 1767 1587 1835 1897 1937 1884 0432 0558 1420 0540 0170 1879 1789 1559 1449 0110 0588 1435 1949 0209
	VCR	1568
	SAT	4303
	COMBI	1598 1938 0043 1835 0514 1069 1882 1443 1836 0299 1461 1957 0556
	DTT	1838 5293 1057
SCHAUEN	TV	1423
SCHNEIDER	TV	0209 0513 0043 1423 1048 1027 1031 0557 0170 0415 0097 5241 0359 1452 0006 0044 0432 1516 0556 0440 1207 0322 0592 1966 5957 1942 1838 0589 1454 0201 1235 0162 0352 0552 1760 1938 0554 5596 1837 1269 0141 1420 1868 0522 1393 1069 1879 0225 0008 1598 0399 1383 0045 1400 1594
	COMBI	0043 0522 1443 1423 1069
SCHNEIDER (F)	see	PHILIPS
SCHNEIDER ELECTRIC	see	SCHNEIDER
SCHONTECH	TV	1048 0043 1423
	COMBI	43
SCHULTS	TV	43
SCHWAIGER	SAT	4303 4541 4288 4127 4214 1862
	DTT	4541 4288 4214 1862
SCIENTIFIC ATLANTA	see	SCIENTIFIC
SCION - TECH	see	SCHONTECH
SCOTLAND	TV	513
SCOTT	TV	0513 0044 1721 1985 1638 1813 0488 1897 1526 1343 5252 5937 0540 0547 0595 1876
	COMBI	1482 0044 1897
SCREENLAND	TV	1423
SCREENSERVICES	TV	35
	COMBI	1854
SCREENVISION	TV	0561 1523 1606 0595 0513 0406 1539 0322 1589 1439 0528 1311 0359 0529 0547 1338 1807 1933 0051 1528 1934 0209 0373 0167 1942 0587 1798 1315 1941 1382 1785 1376 1811 1301 1810 1269 1445 1251 5900 1313 1800 0557 1935 1302 0579 1808 1849 1929 1930 1931 1243 1809 1936 1428 1787 0565
SEARCH	COMBI	34
SEARS	see	SANYO
SEATEC	TV	1633
SEAWAY	TV	0043 0209
SEDEA	TV	1048 0433
	SAT	0919 4321 4288
	DTT	4288
SEDIP	see	PATHE CINEMA
SEELTECH	TV	0008 0556 0484 1068
	COMBI	1482 1865
SEELVER	TV	0170 1452 0589 0043 1537
SEEVUE	TV	0423 1201 0485
SEC	TV	0043 1423 0513 0552 1249 0097 1838 0359 1393 0322 1942 0540 0128 0433 1809 1837 0162 0555 0209 1412 0589 0021 1142 0599 0167 1048
	SAT	4321
	COMBI	0043 1423 0484
SEC TOKYO	TV	1423
SEI	see	SINUDYNE
SEIGA	see	mitsubishi
SEIKI	TV	5248
SEIKO	TV	0557 1837
SEIKON	TV	1937 0550 1891

Brand	Type	Code
SEITECH	TV	0556 0589 1975 1400 0557 1833 1452 1398 0592 1396 1850 1434 1397
SELECLINE	TV	1048 1027 0110 0011
SELECO	TV	0440 1642 0043 0513 1207 1600 0170 0352 0541 0589 0522 1423 0162 1491 0147 1546 1027 0548 1351 0528 0351 0209 1862 0584 1863 1459 0171 1142 5251 1384
	SAT	0785 4288
	COMBI	0043 0540
	DTT	4288
SELECT	TV	0097 0043
SELTEKA	TV	419
SELTEN	TV	1423
SELT	TV	1555
SEMP	TV	467
SENATOR	TV	359
SENCOR	TV	1938 1838 1351 1400 0484 1201 0110 1839 1282 1831 0592 1247 1001 5841 5271 1027
SENCORA	TV	359
SENDAY	TV	513
SENEL	TV	0043 0351 0557 0589 1942 1423 0513 1429 0097 0556 0427 0540 1838 1313 0552 0585 0359 1479 1366 1207 0586 0352 0528 0495 1466 0467 0141 1400 0541 1393 1249 0415 0336 1657 0337 0322 0547 0529 1572 1589 0167 0400 1470 0145 1251 0579 1112 1485 0070 0565 0595 0561 1300 0339 0140 1333 0051 0021
	SAT	4303 0919 4541 0589 0513 4506 4787
	COMBI	1443 1836 0043 0513
SENSI	TV	1450 1412 1449 1758 1759 1453 1459 1760 1966
SENSOY	TV	1606
SENSY	TV	1966
	COMBI	1938
SENTRA	TV	0162 0337
SENYU	TV	0467 0529 0351 0513 0373 0209 0339 1313 1890 0528 0495 0473 0496 0427 0584 0472 0097 0552
SEPIA	TV	288
SERINO	TV	0073 0424
SET	TV	0513 0162
SETRON	TV	0359 0322
SFERE	TV	201
SHADOW	TV	1423 0043
	COMBI	43
SHADOWCHINE	COMBI	43
SHARK	SAT	4303
SHARM	TV	557
SHARP	TV	1429 0532 1885 0202 1114 1421 1423 1108 1109 1080 0045 1048 5250 5956 0513 5263 1726 1401 0359 1090 5879 0351 0043 0352 1014
	VCR	1429
	DVD	1429
	COMBI	1429 1423
SHERTON	TV	359
SHERWOOD	TV	557
SHIMATSU	TV	1556
SHINELCO	TV	0263 0550 1091 0449 1949 1559 1789 0101 1551 1578 0033 1537 1536 0244 1529 1577 1011 1897
	COMBI	0449 0299 1897 1091
SHINTOM	TV	0513 0043
SHINTOSHI	TV	513
SHIVAKI	TV	0513 0043 0322 1429 1539 0097 1523
SHIWAN	TV	424
SHNIED	TV	322
SHOGUN	TV	359
SHONY	TV	73
SHORAI	TV	0300 0424
SHOV	TV	0359 0322 0513 0595 0561 0415 0352 0556
SHOW	see	SHOV
SICANTIC	see	LUXOR
SICE	TV	351
SIEMENS	TV	0351 0513 0589 1743 5738 1423 0359
	SAT	589
	COMBI	1443 0540
	DTT	4541
SIEMSSSEN	TV	1454
SIERA	TV	0352 0170 0513 1452
	DVD	352
	SAT	785
	COMBI	0522 1463
	HIFI	513
SIESTA	TV	0336 1207 1657 0513 1849 0352 0322 1429
SIGMA	SAT	4541
	DTT	4541
SIGMA DESIGN	see	SIGMA
SIKURA	TV	100
SILK	TV	100
SILMA	TV	513
SILVA	TV	0322 0589 1838 0513 0359 0440 1454 1516 1048 1423 1938
	COMBI	1443
SILVA SCHNEIDER	see	SCHNEIDER
SILVER	TV	0322 0359 1027 0043 0170 0513 1235
SILVERCREST	TV	0043 1423 1249 1142 1393 1023 1847 1048
	SAT	4288
	COMBI	43
	DTT	4288
SIM 2	TV	0589 1904
	SAT	785
SIMATEC	see	ORION
SIMPLI TV	TV	1664
SIMTEL	TV	0513 0322 0424

Brand	Type	Code
SINGER	TV	0513 0209 0359 0415 0433 0164 1638 1311 1642 0170 0373 0336 0043 0300 1423 1207 0352
SINOTEC	see	SINOTECH
SINOTECH	TV	1798 1282 0595 1604 0483 1251 1420 0322 0561 1084 1048 5764
SINUDYNE	TV	0513 1207 0170 0555 0588 0556 1452 0589 0471 5886 0352 0300 0484 1423 1400 1048 1975 1516 0359 0440 0043 0528 1434 0594 1833 1242 1396 1511 0581 0101 0540 0592 1395 1578 1429 5586 1541 0209 1642 1850 1459 5548 1397
	COMBI	1598
SIYAH	TV	0557 0141
SKANTIC	see	LUXOR
SKAY	TV	1301 0424 0513
SKINTEK	TV	1450 1511 1793
SKY	TV	1756 1794 1412 1964 1597 1450 1952 1383 1758
	SAT	4541 0733 4603 4274 4288 4749 4594 4617 4618 4326 4309 4308 5428
SKY DEUTSCHLAND	SAT	5428 4603 5146
SKY GERMANY	SAT	4990
SKY ITALIA	SAT	4749 4274 0733 4594 4603 5724 5146
SKY MEDIA	TV	1991 1952 1597 1756 1951 1964 1412 1450
SKY NET	SAT	4620
SKY NEW ZELAND	SAT	4326
SKY TURCHIA	SAT	4787
SKY VIEW	SAT	4541
	DTT	4541
SKY VISION	SAT	4541
SKYBOX	SAT	4506 4603
SKYLINE	TV	141
	SAT	4541
	DTT	4541
SKYMASTER	SAT	4541
	DTT	4541
SKYPLUS	SAT	4541 4288 4594
	DTT	4541 4288
SKYSAT	SAT	4321 4214
SKYSTAR	SAT	4214
SKYTECH	TV	0550 0011 1765 1937 1891
SKYTRONIC	TV	1420 0359 0513
SKYWORTH	TV	1282 1604 0359 0513 5763 5880 0579
SL	SAT	4288
SLIDING	TV	1516 1383 1564 0556 1412 1569 1555 1453 1549
	COMBI	556
SLING MEDIA	SAT	5718
SLX	TV	0589 0097
SMARAGD	TV	549
SMART	TV	5242 1027
	SAT	4910 0686
SMART TECH	TV	1027 5446 5242 5927 5830 5997
SMARTIX	DTT	5320
SMARTVISION	TV	1506 1556 0145 1741 1594 1731 0557 1872 0205 1726
SMC	TV	1437
SMD	DTT	4541
SODIFF	TV	1793 5298
SOEMTRON	TV	1383
SOFRATEL	TV	1423
SOGERA	TV	513
SOGO	TV	0484 1400 0432 1837 1027 0557 5307 1559 1220 0579 1201 0589 0306 1966 1838 1384 5242
SOLARIS	SAT	919
SOLAVOX	TV	0162 0433 0513
SOLTECH	TV	1338
SOMBER	see	CLARIVOX
SOMMIGE MERKEN	TV	0557 0141
SONIC	TV	0467 1890
	COMBI	366
SONICLINE	TV	541
SONICX	TV	513
SONIKO	TV	1657 0513 0359 0162
SONIQ	COMBI	5557
SONITRON	TV	0373 0589
SONIX	TV	1450 1536
SONNECLAIR	TV	513
SONOKO	TV	0359 0513 0322 1027 1157 0557 0043 0424 1604 0415 0471 1175 1282 0488
SONOLOR	TV	0433 0373
SONORO	see	AGASHI
SONTEC	TV	0513 1657 0359
SONY	TV	1309 0495 1313 1308 0339 0140 5220 5221 1178 1333 1300 1084 1528 1310 0373 1936 1800 1530 0785 1316 1014 5521 1356 0351 0513 0064 1420 0540 1366 1048 5895 5522
	VCR	0339 1313 1309
	SAT	0733 0785
	COMBI	1310 0495 1313
SOUND CANDY	TV	1201
SOUND COLOR	TV	0589 0513 1638 0043 0415 0557 0097 1452 0322 0141 1423 1657 0170
	COMBI	1443
SOUND DESIGN	TV	547
SOUND VISION	TV	513
SOUNDMASTER	TV	359
SOUNDWAVE	TV	0513 1420 0141 1423 0170 0322 0043 0162
SOUNDZONE	COMBI	1598
SOWTECH	TV	1657
SOYOCA	see	SOYOKA
SP@CE DIGITAL	DTT	5440
SPARKLE	TV	513
SPECTRA	TV	0359 0513 0322 1112 0579 0595 0561 1259

Brand	Type	Code
SPECTRA VIDEO	TV	0426 1983
SPECTRUM	TV	0547 5279
SPLASH VISION	TV	5882
SPORT GENEXXA	see	FORMENTI
SRD	SAT	4127 4214
SSANGYONG	TV	1638 0359
SSS	see	FUNAI
STAB USUAL	SAT	919
STAN - LINE	TV	432
STANDARD	TV	0359 0513 0209 0043 1529 1876 0008 1100
STAR	TV	513
STAR DIGITAL	SAT	744
STAR SAT	SAT	919
STAR TRACK	SAT	919
STARCOM	SAT	4321
STARDUST	TV	513
STARION	TV	1423 1838
STARLIGHT	TV	1351 1441
	SAT	4166
STARLINE	TV	513
STARLITE	TV	1638 0359 0322 0097 1011 0513 0557
	COMBI	1883
STARLUX	TV	0359 0322 0513
STARRING	TV	359
STARS	TV	352
START	TV	513
STARVIEW	SAT	5251
STASSFURT	see	BRUNS
STELLA	see	CONNEXIONS
STENWAY	TV	424
STERLING	TV	0043 0170 0589 1434 1207
STERN	see	SELECO
STILANDIA	TV	472
STM	TV	433
STOREX	DTT	4383
STRATO	TV	1400 0513 0322 0359 1874 1840 1423
STREAM	TV	0205 1201
	SAT	4303 0733
STREAM - SYSTEM	TV	0205 1027
	SAT	5544
STREAM TV	SAT	733
STRONG	TV	1282 1423 1393 1215 0548 1201 1217 1586 1604 1048 5216 1140
	SAT	0785 4506
	PC	5597
	DTT	0917 0785
STT SONIC	TV	0513 0471
STVI	SAT	785
STYLANDIA	TV	359
SUGDEN - AUDIO	see	SUGDEN
SULPLICE - TV	TV	1048
SUN	TV	1975
SUNFEEL	TV	1048 1423
SUNGOO	TV	1396
SUNIC LINE	TV	0209 0513
SUNKAI	TV	0043 0513 0300 0549 1352 0073 1383 0424 0589 0557 0588
	SAT	919
	COMBI	0043 0537
SUNLIC	TV	513
SUNMOONSTAR	DTT	917
SUNNY	TV	1921 1486 1384 1966 1449 0550 1338 0507 0415 0359 1529 0513 0484 1423 5307
	SAT	4303 4541
SUNNYSKY	TV	426
SUNSTAR	TV	0513 0359 0322 0043 0589
SUNSTECH	TV	1048 1423 1027 0399 1633 1526 0244 1542 0576 1897 0488 1489 1537 5515 1449 1146 0487 1001
	COMBI	1897 0128 0487 0488 0188 1001 0399 0324 0225 0325 1423
SUNWATT	TV	0513 0471
SUNWOOD	TV	0513 0359
SUNY	TV	1449 1550
SUPER GENERAL	TV	0513 0556 0589
SUPER LCD	TV	1595
SUPERIOR	TV	0043 1423 1249 0097 1393 0513 1942 0552 0589
	COMBI	43
SUPERLA	TV	0513 0322 0359 0162
SUPERMAX	see	SUPER MAX
SUPERSCAN	TV	1558
SUPERSONIC	TV	0322 0373 0513 0415 0424 0359 0043 0541 5798
SUPERTECH	TV	0359 1638 0513 0073 0415 0043 0322
	COMBI	359
SUPERVISION	TV	359
SUPERVOX	TV	1207 0170
SUPEX	see	SUPEXS
SUPRA	TV	0513 0359 0547 0073 0322 0529 0415 1500 1351
	COMBI	537
SUPRATECH	TV	0484 1001 0263 1111
	SAT	5954
	COMBI	0002 0484 1111
SUPREME	TV	73
SUTRON	TV	359
SUTUM	TV	359
SUUNY	see	SUNNY
SVA	TV	0561 1849 1376
SVAN	TV	1048 1384 5426
SWAN	TV	1048
SWEDX	TV	1716
SWEEX	TV	0484 0500 1835
SWEYK	TV	1939
SWING	TV	170

Brand	Type	Code
SWISSCOM	SAT	4849
SWISSTEC	TV	1756 1794 1412 1952 1964 1450 5884 1597 1951 1410
SYC LINE	TV	359
SYNIX	TV	5251
SYLVANIA	TV	1558
SYMPHONIC	TV	1558
SYNAPS	DTT	0686 5294
SYSLINE	TV	513
SYSTEC	SAT	4541
	DTT	4541
SYSTEL	TV	359
SYSTEM FIDELITY	HIFI	5508
SYTEC SAT	SAT	4541
	DTT	4541
SYTECH	TV	1915
SYTEK	TV	1915 0053
T - LOGIC	TV	0286 0546
T - URAS	COMBI	1938
T.V.E.	COMBI	43
TADISTAR	TV	1420 0513 0561
TAHOCI	TV	322
TAISHO	COMBI	1598
TAIWAH	TV	513
TAKANAWA	TV	359
TAKARA	TV	0043 1971
	COMBI	1835
TALENT	TV	351
TALITA	see	CLARIVOX
TAMASHI	TV	424
TAMIX	TV	1873
TANDBERG	TV	0440 0170 1033 1642
TANRA	TV	43
TARCA	TV	0594 1983 1459 0513 1896
	COMBI	1078
TASHIKO	TV	162
TASTER	TV	0513 0322 0471
TATUNG	TV	0513 1979 0541 0589 1643 1434 1207 0556 0170 1459 1396 1817 0043 1443 0508 0471 1423 1756 0555 1452
	COMBI	1598
TAURAS	TV	0556 0522 1937 0592
	COMBI	0556 1069
TAURO	TV	541
TAYRAS	TV	592
TCE SERVICE	TV	164
TCHIBO	TV	0209 1400
TCL	TV	0548 5216 1217 0367 1060 1523 0561 1539 0498 1423 0263 1494 5572
TCM	TV	0209 1400
TD	TV	432
TD DESIGN	TV	508
TD SYSTEMS	TV	0432 5858 1175 1048 5275 5273 1201 1109 1423 5860 5211 5859 1027
	COMBI	1423
TDA COLOR	TV	557
TEAC/TEAK	TV	0561 0513 1523 0498 1423 1986 0599 0043 0012 1269 0376 0557 1719 1006 5284 1048 0359 0592 0097 0015 1357 0085 0547 0440 0552 1722 0322 0471 1629 0489
	COMBI	85
TEAM	TV	424
TEC	see	DUAL
TECCO	TV	0359 1423
TECH	TV	1949
TECHLINE	TV	0043 1423 0513 0097 1838 0552 1837 1249
	COMBI	43
TECHLY	DTT	5320
TECHMADE	DTT	4432
TECHMAX	TV	101
TECHNE	TV	1512 1793
TECHNEMA	TV	0513 6022 0527
TECHNICA	TV	1938 0043 1114 1423 1048 0556 0589 0359 1966 1678 1939 1847 0576 1036 1069
	COMBI	0043 1899
TECHNICAL	TV	0043 1048 1423 1757
	COMBI	43
TECHNICOLOR	SAT	5718
TECHNICS	TV	0427 0359
TECHNIKA	see	TECHNICA
TECHNILAND	TV	513
TECHNIMAGEN	TV	1452 0170 1207 0352 0589
TECHNISAT	TV	1268 0555 4214 0540 5802 0513 0043 0594 1207
	SAT	4127 4214 1862 0585 0540 1577
	DTT	4127 4214 1862 1577
TECHNISSON	TV	0557 0026
TECHNO	TV	1879 1849
	COMBI	43
TECHNOBOX	TV	5242 1927
TECHNOL	TV	0322 0513 0359 0043 0508
TECHNOLOGIC	TV	546
TECHNOMATE	SAT	5297 1382 5800
TECHNOSAT	SAT	4303
TECHNOSONIC	TV	0556 0550 1760 0589 1840
	COMBI	1461
TECHNOSTAR	TV	484
TECHNOTREND	TV	423
TECHONE	TV	1410
TECHVISION	TV	1760 1529 1740 1840 1518 1839 0101
TECHWOOD	TV	1423 0043 1048 1393 1887 1249 0513 0073 1847 0432 1400 0209
	SAT	4321
	COMBI	0043 0487 1423
TECKTON	TV	1548 0594 1450
TECNIMAGEN	TV	1452 0170 1207 0589 0352 0010

Brand	Type	Code
TECNISON	TV	0513 0359 0043 1423
TECNOIT	see	TECHNOIT
TECO	TV	1044 1848 1042 1904 1831 5793 1484 1976
TECSONIC	COMBI	43
TEDELEX	TV	1523 0561 0359 1251 0322 0513 1243 1556 1807 1311 1539 1852 1529 1831 1933 1914 1782 0471
	COMBI	1961
TEINELSA	TV	513
TEK	TV	1127 0595
TEKA	TV	1127
TEKNANT	TV	0513 0424 0359
TEKNIKA	TV	1114
TEKO	TV	0589 1484
TEKON	TV	359
TELCA	DVD	43
	COMBI	43
TELE +	SAT	785
TELEAVIA	see	THOMSON
TELECHROM	TV	0424 0513
TELECO	TV	1048 1897 0225
	DTT	917
TELECOM	SAT	4419
	DTT	5161 4419 0744
TELECOR	TV	0513 0540
TELEDESIGN	TV	508
TELEFAC	see	FORMENTI
TELEFUNKEN	TV	0164 1048 1423 0051 0043 0563 0589 0513 0006 1300 0561 1494 0141 1809 1622 0162 0579 1338 1807 1941 1942 1685 1301 1415 1808 1810 1811 1428 0405 1269 1376 0595 1938 1838 0548 5558 5299 1400 0026 1109 0537 0484 1235 0359 1429 0552 1539 0528 0540 1464 0585 1454 1606 0286 0201 1489 5295 5936 0351 1837 1298 1847 0557 1282
	SAT	589
	COMBI	1423 0537 0043 1443 1811 1938 1048
TELEFUSION	TV	0513 0540
TELEGAZI	TV	0513 0541 0359 0322 0162
TELEKA	TV	1423
TELEKTRON	TV	359
TELEMANN	SAT	4148
TELEMASTER	TV	513
TELEMEISTER	TV	513
TELENET	TV	81
TELEOPTA	TV	0359 0513
TELEPAC	TV	359
TELEPOINT	TV	513
TELERENT	TV	508
TELESERVICE	SAT	785
TELESONIC	TV	0513 1207 1338 0555 0043
TELESTAR	TV	0513 0589 0336 1420 0359 0322 1590 0556
	SAT	4214 4541 4127 4321 0585
	COMBI	1443
	DTT	4214 4541 4127
TELESYSTEM	TV	1838 5554 1475 1423 5239 0101 1400 1168 0366 5553 0043 5569 5798 0489 5540 1595 1343 1902 1247 1831 0484 1027 0557 1548 5572 1357 0205 5567 5573 5273 5998 1927 6027 6032
	SAT	4506 0785 0788
	COMBI	1423 0489 1838 0484
	DTT	4303 4432 5239 5553 6030
TELETECH	TV	0043 0513 0097 1423 0556 0359 1878 1393 1376
	SAT	4321
	COMBI	43
TELETEK	see	TELETHEK
TELETON	TV	440
TELEVES	SAT	4288
	DTT	4541
TELEVIDEON	TV	0513 0359 0322 0162
TELEVIEW	TV	0589 0043 1437 1412 0556 1249 1743 0128 1454 1435 0351 0209 1838 0557 0528 0513 0552
	SAT	4321 4288
TELEWIRE	TV	0110 1839 0101
	SAT	4419
TELEWIZIA	SAT	4759
TELKA	COMBI	43
TELKOM	TV	0513 0351 0337
	SAT	4321 0919
TELPAS	SAT	4541
TELRA	TV	0589 0513 1454 0162
	COMBI	1443 1461
TELSTRA	SAT	5146
TEMCO	see	SHORAI
TEMPEST	TV	0359 0513 0540
TENNESSEE	TV	513
TENSAI	TV	0513 0359 0043 0415 0209 0541 0097 0170 0557 0579 1423 0352 0549 0141 1502 0471 5834
TENSON	TV	359
TERMAL	SAT	919
TERRA	TV	0520 5964 0053
TERRATEC	TV	5249
TERRIS	TV	5545 0110
TESCO	TV	5958 0367 1052
TESLA	TV	0513 0592 0043 0209 0557 0548 5945 5970 0073 0555 0097 0540 0170 0556 0579 5764 0415 1642 1604 0351 0141 0471 1142 1423 1282 5763 1837 1247 1685
	SAT	686
	COMBI	43
TESLA SLOW	see	TESLA
TETTRAN	TV	513

Brand	Type	Code
TEVION	TV	0557 0043 0209 1396 0589 1249 1578 0097 1400 1884 1788 1423 0556 1415 1839 0141 1435 1739 1838 0552 1069 5960
	COMBI	1836 1461 0043
TEWA	TV	415
TFT	TV	5256
THES	TV	1903 1928 0013 1440 0087 0423 1989 1988 1813 1831 1677 0128 0576 1155 1526 0244 1897 0019 5978
	COMBI	1831
THOMA	SAT	4506
THOMSON	TV	0051 0548 0351 1060 5981 5216 0367 0549 1217 5980 0467 1143 1445 0164 0513 1996 1435 1207 0557 1606 1789 0352 1494 1429 0588 1247 1070 0540 0537 0366
	VCR	0051 0537 1445
	DVD	51
	SAT	0785 0051 0733 4618 4594 4617 4274 0744
	COMBI	0051 1445 0537
	HIFI	1143
	DTT	0785 0917
THOR	TV	5959
THORENS	HIFI	1337
THORN	TV	0051 0513 0467 0337 0373 0527 0209 1313 0322 0339 1429 0351 1300 0540 0541 0529 0556 1638 0495 0162 0359 0440 0352 0170 0427 1207 0415 0471 0205
	VCR	51
	SAT	919
	COMBI	537
THORN EMI	TV	351
THUNDERMAX	SAT	785
TILE TELEVISION	TV	1451 1840
TIM	SAT	4419 5718 0744
	DTT	5161
TIM VISION	see	TIM
TIME	TV	1489 1896 1537 1400 1514
TINY	TV	1535
TLC	TV	286
TMK	TV	547
TMX	SAT	785
TOBBE	TV	1716
TOBISHI	TV	0322 1338 0359 1760 0561
TOBO	TV	0359 0322
TOKAI	TV	0043 0513 0162 1027 0359 0432 0243 0352 1633 0322 1638 1423 1831 1525 0097 0471 0319 0484 0500 0110 1129 1201 1897 0128 5251 1175
	COMBI	0243 1897
TOKO	see	KATHREIN
TOKYO	TV	0513 0424 0337
TOMASHI	TV	424
TOMEI	TV	0359 0467
TONOMAC	TV	1726
TOP HOUSE	TV	1726
TOPFIELD	TV	1027
TOPLINE	TV	0043 0097
TOPSECTOR	TV	0359 0513
TOPSHOW	TV	0322 0561
TOPVISION	TV	0336 0513 0162 0555
TORRE	see	THOMSON
TOSHEBIA	TV	595
TOSHIBA	TV	0467 0019 1890 0109 1466 0337 0021 1165 0018 1048 1423 0351 1885 1075 0513 0557 1757 0205 0043 5236 1837 0110 5900 0352 1422 0064 5747 1027 0547 0141 1429
	VCR	0467 1466 0534
	DVD	1048
	SAT	4487
	COMBI	1075 1423 0064
TOSUMI	TV	0043 1837 1536
TPS	SAT	744
	DTT	744
TPV	TV	1494
TRANS CONTINENTS	TV	0043 0170 1452 0589 1207 0541 0097 0336 1400 0513 0141 0588 1383 1434 0557 1537 1453 1569 1564 1437 0592
TRANSONIC	TV	0513 0322 0508 0528
TRAXIS	SAT	4288
	DTT	4288
TRENTON	TV	1423
TREVI	TV	1027 0507 1129 1525 1966 0583 5890 0359 1549 1594 1235 1343 1529 0188 1633 5556 5426 1201 5355 0424 1595 1873 0500 5354 0599 0484
	DVD	1146
	COMBI	0500 0583 0188 0483 0484 1966
TRIAD	TV	0513 0540
TRIASAT	see	WISI
TRIAx	SAT	4303 4214 4321 5277 0785 0744 5296
	DTT	4432 4214 5296
TRIDENT	TV	513
TRILUX	TV	1980 0043 0336 0209 0513 0097
TRING	see	TRING DIGITAL
TRINITY	TV	1525
TRIO	TV	1428 1396 1781 1817 1475
TRION	TV	43
TRISTAR	TV	0322 0513 1420 0471
TRIUMPH	TV	0508 0513
TRMISION	TV	359
TRONIX	TV	359
TRONY	TV	561
TS VISION	TV	1873 0188 0483
	COMBI	483
TSL	TV	1523
TSOSHI	TV	424

Brand	Type	Code
TTR	TV	1455 0043
TUCSON	TV	1048 1423
TUDOR	TV	1460
TURBO - X	see	TURBOX
TURBOX	TV	1048 1423 1027
TURNO	TV	1685
TV - TECH	TV	1384
TV CABO	SAT	744
	DTT	51
TV MAX	SAT	4288
	DTT	4288
TV SISTEM	TV	1048
TV STAR	TV	1027 1091
	COMBI	583
TV+	TV	1400
TVD	TV	43
TVE	COMBI	1938 0043
TVEMAX	SAT	4288
TVH	TV	322
TVT	TV	485
TVTUNERCARD	TV	1959
TWF	TV	1514
TWIN	TV	1897
TWINNER	SAT	4541
	DTT	4541
TWINSAT	SAT	4321
TYP	TV	43
TYPHOON	TV	1412
UHER	TV	0513 0508 1942 0043 0540
ULTRAVOX	TV	0513 1423 0557 0043 1247 1070 1726 1393 0550 0592
UMC	TV	1036 1756 1678 1597 1951 0325 5915
	COMBI	1678
UML	TV	1036
UNIC	see	UNIC RADIO
UNIC LINE	TV	0513 0541 0209 0043
UNIC RADIO	TV	0513 1657 0541 0162
UNIDEN	TV	0043 1382 0541
UNIMOR	TV	0336 1657 0513
UNITECH	TV	0513 1469 0557 0352 1598 1529
	COMBI	1598
UNITED	TV	0557 0399 1247 0141 0541 1423 0513 1838 5900 0097 0043 0556 0110 1469 1837 1070 5566 0201 0319 0423 1789 0288 0351 1282 1949 1831 0145 1400 1988 1879 1587 1460 1559 0101 1215 1897 1989 1847 0500 0019 0325 0036 1133 5348 5893 1201 5586 0336 1657 1839 1440 0359 1541 1595 1435 0467 0188 0511 1598 0109 0162 5204 0583 0366 1062 5596 1865 1441 1794
	COMBI	1598 0043 0325 0225 0399 1897 1871 1882 0357 1938 1838 1876 1423 1988 0288 1847 0019
	DTT	5320
UNITEK	see	UNITECH
UNITRON	TV	595
UNITRONIC	TV	0101 0359
UNIVERSAL	TV	0325 0513 1383 1393
UNIVOX	TV	513
UNK	TV	0097 0513 0043 0557 1435 1880
UPC	SAT	0744 4303
UPXUS	TV	43
URANIA	see	SAMBERS
URANYA	TV	0513 0359 0322 0100
URMET	TV	5905
UTAX	TV	359
V 7 TV	TV	1450
VANGUARD	TV	1048 1423 0359 0043
VANTAGE	TV	43
VARIOSAT	see	WISI
VASILINEC	TV	359
VD TECH	TV	1247 0484 0576 0500 1062 1966 5913 0201 1789 0583 0563 0488 1876 0306 0225
	COMBI	0405 0306
VDC	TV	1789 1879 1876
VDC TECH	TV	1876 1879
VECO	TV	0359 0513
VECTOR	TV	1897 0325 0484 0563 0483 0514
VECTOR VISION	see	VECTOR
VEGA	TV	1112
VELTECH	TV	1556
VENTANA	TV	43
VENTURA	COMBI	1899
VESTEL	TV	0043 0513 1423 1048 0097 0552 1249 0540 1393 1942 0021 0589 1685 0352 1450 1383 0561 0550 0209 1495 1142
	SAT	4321 1423
	COMBI	0043 1423 0552
VEXA	TV	0513 0424 0359 0352
VIA	SAT	791
VICEROY	TV	322
VICTORY	SAT	919
VIDECON	TV	0110 0513 0471 0322
VIDEO 7	TV	1450 1743 1412 0594 0565
VIDEO CIVEN	TV	594
VIDEO CLUB	see	VIDEO ELECTR. CLUB
VIDEOCOLOR	TV	0733 0154
VIDEOCON	TV	0513 0110 0154 0733 0322
VIDEOLÓGIC	TV	322
VIDEOMAC	TV	322
VIDEON	TV	513
VIDEOTEN	TV	1743 1450 1412 0594
VIDEOSYSTEM	TV	0513 0540
VIDEOTON	TV	0162 0043 0513 1420 0097 1423 0359 0322 0540 1743
	COMBI	43

Brand	Type	Code
VIDIKRON	TV	0359 0513
VIDION	TV	0359 0513
VIDITAL	TV	322
VIDO	TV	1523
VIETA	TV	1459
VIEW	TV	1880 1938
VIEWPIA	TV	1475 1911
VIEWSONIC	TV	0053 5917 1955 1494 1951 1086 1489 0202 1979
VIEWSTAR	TV	594
VIKTOR	TV	1716
VIOLA	SAT	4541
	DTT	4541
VIORE	TV	5246
VIRGIN MEDIA	SAT	5522 5278
VISIOLA	see	PATHE CINEMA
VISION	TV	0513 0359 0043 0322 0540 1716
VISION 2000	see	VISION
VISION MAGIC	TV	1412
VISIONIC	SAT	4288 0919
	DTT	4288
VISIOSAT	SAT	4321 4288
VISTA	see	THORN
VISTAR	TV	433
VISTRON	TV	0299 1011
VITEK	TV	1525
VIVAX	TV	0110 1384 1526 1964 0557 1813 1901 1027 1924 1529 1594 1595 1900 0484 1137 0145 1506 1731 0550 1571 1201 5951 1400 0556 1872 1343 1040 0101 1048 0548 1282
VMD	TV	432
	COMBI	432
VIZIO	TV	5808
VIZYON	SAT	4303 0686
VODAFONE	SAT	5718
VOG	TV	1452 0513 0471
VOGELS	TV	1759
VONINO	TV	5554
VORKE	TV	1873
VORTEC	TV	0513 0145 0540
VORTEX	TV	5251 1201 0145 1027
VOX	TV	1048 1870 0550 1423
VOXON	see	VOXSON
VOXSON	TV	0043 1400 0556 0557 1410 0513 1396 0145 1848 1904 1938 1422 1789 1469 0588 1460 1423 1484 1489 1837 1529 0322 1401 0589 1537 1395 1536 1963 1397 1394 1042
	COMBI	1938 1526 1897
VOYAGER	TV	513
VTEK	see	VTECH
VTEX	TV	5426
WAGNER	TV	513
WAITEC	TV	1597
WALKER	TV	1048 0043 1423
WALKIE	TV	440
WALKVISION	TV	43
	COMBI	43
WALTHAM	TV	0043 0513 0162 1423 1420 1048 0097 0359 5886 1743 0540 0322
	COMBI	43
WATSON	TV	0513 0043 0097 0322 0359 0552 1450 1423 0209 1952 1249 1455 1393 1942 0589 0471 0373 0557 1794
	COMBI	43
WATVISION	TV	1423 1393 0043
WATT RADIO	TV	1420 0513 0209 1207 0008 1657 0170 1452 0087 0440 0359 0043 1526 1410 1938
WAVE	TV	589
WAVELICHT	SAT	919
WDEZI	TV	1027
WEBER	TV	0322 0359 0513
WEG	TV	145
WEGA COLOR	see	WEGA VISION
WEGAVOX	TV	0043 1423 0513 0556 1420 0097 1511 0555 0336 0359 0322 0376 0592 1529 0541 1833 1410 0557 0141 0528 0552 1469 1726
WELLFUND	TV	0424 0513
WELLINGTON	TV	0043 1423 1048
	COMBI	0043 1423
WELLTECH	TV	557
WELSTAR	TV	1423 0043
	COMBI	43
WELTBlich	TV	0513 0541 1638
WELTBlick	see	WELTBlich
WEST POINT	TV	1420
WESTINGHOUSE	see	WHITE WESTINGHOUSE
WESTLINE	TV	1048
WESTON	TV	0162 0424 0540
WESTWOOD	TV	0043 1048 1423 1838
	COMBI	43
WHARFEDALE	TV	1423 0043 0589 1807 1887 1338 0513 1809 0359 1831 1900 0592 1491 0556 1393 1974 0170 1012 1437
	COMBI	1901 1961
WHITE WESTINGHOUSE	TV	0513 1638 1420 0043 0162 0541 0359 0322 1944 1142 0540 0424 0589 0051 1269 0552 1423
WICOM	SAT	686
WILSON	TV	0170 0043 1452 0589 0592 1434 1453 1572
WINCO	TV	322
WINDSOR	TV	0043 0097 1423 0513 1048
	COMBI	43
WINDSTAR	see	THORN
WINDY SAM	TV	540
WINERSAT	TV	0359 0424
WINNER	TV	359

Brand	Type	Code
WINS	TV	1338
WINSON	TV	557
WINSTON	TV	0359 0513 0424 0043
WINTAL	TV	1551
WINTERNITZ	TV	0359 0097
WISI	SAT	4127 4214 0585 4303
WIZIA	TV	586
WORLD	COMBI	1598
WORLD OF VISION	TV	1975 0557 0589 1383 1597 1412
WORLD TECH	TV	513
WORLDSAT	SAT	4321
	DTT	917
WORLDVIEW	TV	0513 0359 0415 0471
WORTEN	TV	0073 0209 0589 0513
WOV	TV	1450 1975
WOXTER	TV	484
WZRD	TV	0513 1081 1122 1927 1309 0534
	SAT	5324
X - TERM	SAT	4303
XCELLENT	TV	1638 1338 0513
XD	see	XD - ENJOY
XD - ENJOY	TV	1048 1027 5446 5554
XDOME	TV	1633
	DTT	5440 5320
XENIUS	TV	5931
	COMBI	1861
XEOBOX	SAT	686
XION	TV	1428
XIRON	TV	0073 0043 1423 0209 0589 0513
	COMBI	43
XMHELLO	TV	498
XOMAX	COMBI	576
XONYCS	TV	513
XORO	TV	1741 1030 5251 0484 5931 1134 1629 1133 1906 1831 1220
	SAT	686
	COMBI	556
XRIPTON	TV	0513 1638 1420
XTREAMER	TV	1235
XTREME	SAT	4303
XTREND	SAT	35
YAKUMO	TV	1756
YALOS	TV	1740
YAMAHA	TV	43
YAMAJI	TV	1423
YAMISHI	TV	0424 0540
YENMADE	TV	359
YES	SAT	4326
YOCAN	TV	540
YOKAN	see	YOCAN
YOKO	TV	0513 0359 0322 0516 0162 0337 0540
YORK	TV	359
YOSHITA	TV	513
YOTAKA	TV	513
YTAWAI	TV	1410 1440
YUMATU	TV	1420 0359 1112 0322 0556 0513 0415 0579 1251 1849 1235
YURAKU	TV	1475
YUSMART	TV	1423 1851
ZANELA	TV	1429
ZANUS	TV	554
ZANUSSI	see	SELECO
ZEHNDER	SAT	4321 4541
	DTT	4541
ZENITH	TV	5426 5211 5242 1384 5307 5308 0432 1027 5369
ZENOR	TV	373
ZENYTH	see	ZENITH
ZEPHIR	TV	0432 5103 1387 1351 5903 0546 5546 5446 5902 1837 5259 1027 5251 5328 1996 1966 5983 5271
	DTT	5103 4432
ZEPHYR	see	ZEPHIR
ZEPTO	TV	43
ZEUS	TV	1423
ZINTEK	TV	205
ZIRCON	SAT	5294
ZIRWATEL	TV	0359 0513 0051 1313
ZODIAC	SAT	0919 0373
	DTT	919
ZOPPAS	see	SELECO
ZOTA	TV	0513 0471
ZX	TV	359

